

# Industrial Cellular VPN Router



## NR500 Pro User Manual



## REVISION HISTORY

Revision	Date	Firmware Version	Revision Details
0	July 2023	3.0.0(fa20ec1-1)	Initial release.
1	April 2024	3.0.0(fa20ec1-1)	Update Serial Port baud rate
2	May 2024	3.0.0(fa20ec1-1)	Update Order Information

## Trademarks and copyright

Guangzhou Navigatworx Technologies Co, Ltd and  &  logo are the trademarks or registered trademarks in China mainland, HongKong and other countries worldwide. All other trademarks mentioned in this document are the property of their respective owners. ©2018 Navigatworx Technologies. All Rights Reserved.

## Disclaimers

Information in this document is subject to change without notice and does not represent a commitment on the part of Navigatworx Technologies.

Navigatworx Technologies provides this document as is, without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Navigatworx Technologies may make improvements and/or changes in this manual, or in the product(s) and/or the program(s) described in this manual at any time.

Information provided in this manual is intended to be accurate and reliable. However, Navigatworx Technologies assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.

## Technical Support

**E-mail:** support@navigatworx.com  
info@navigatworx.com

**Web:** www.navigatworx.com

## Interference Issues

Avoid possible radio frequency (RF) interference by following these guidelines:

- The use of cellular telephones or devices in aircraft is illegal. Use in aircraft may endanger operation and disrupt the cellular network. Failure to observe this restriction may result in suspension or denial of cellular services to the offender, legal action, or both.
- Do not operate in the vicinity of gasoline or diesel fuel pumps unless use has been approved or authorized.
- Do not operate in locations where medical equipment that the device could interfere with may be in use.

- Do not operate in fuel depots, chemical plants, or blasting areas unless use has been approved and authorized.
- Use care if operating in the vicinity of protected personal medical devices, i.e., hearing aids and pacemakers.
- Operation in the presence of other electronic equipment may cause interference if equipment is incorrectly protected. Follow recommendations for installation from equipment manufacturers.

### Declaration of Conformity

NR500 Series products are in conformity with the essential requirements and other relevant provisions of the CE and RoHS.



## Table of Contents

Chapter 1. Product Overview .....	5
1.1 Overview .....	5
1.2 Features and Benefits .....	5
1.3 General Specifications .....	6
1.4 Mechanical Specifications .....	9
1.5 Package Checklist .....	10
1.6 Order Information .....	13
Chapter 2. Installation .....	14
2.1 Product Overview .....	14
2.2 LED Indicators .....	15
2.3 Ethernet Port Indicator .....	16
2.4 PIN Definition of Terminal block .....	16
2.5 Reset Button .....	17
2.6 Insert SIM card .....	17
2.7 Install Antenna .....	18
2.8 DIN-rail Mounting .....	19
2.9 Protective Grounding Installation .....	19
2.10 Power Supply Installation .....	20
2.11 Power On The Router .....	20
Chapter 3. Access to Web page .....	21
3.1 PC Configuration .....	21
3.2 Factory Default Settings .....	22
3.3 Login to Web Page .....	23
Chapter 4. Web Configuration .....	24
4.1 Web Interface .....	24
4.2 Overview .....	26
4.2.1 Status .....	26
4.2.2 Syslog .....	28
4.3 Link Management .....	29
4.3.1 Connection Manager .....	29
4.3.2 Cellular .....	32
4.3.3 Ethernet .....	36
4.3.4 Wi-Fi .....	42
4.4 Industrial Interface .....	46
4.4.1 Serial .....	46
4.4.2 Digital IO .....	51
4.5 Network .....	53
4.5.1 Firewall .....	53
4.5.2 Route .....	56
4.5.3 VRRP .....	58
4.5.4 IP Passthrough .....	59
4.6 Applications .....	60

4.6.1 DDNS .....	60
4.6.2 SMS .....	62
4.6.3 Schedule Reboot .....	65
4.6.4 GPS .....	66
4.6.5 Call .....	68
4.7 VPN .....	69
4.7.1 OpenVPN .....	69
4.7.2 IPSec .....	75
4.7.3 GRE .....	78
4.8 Maintenance .....	80
4.8.1 Upgrade .....	80
4.8.2 Software .....	80
4.8.3 System .....	81
4.8.4 Configuration .....	86
4.8.5 Debug Tools .....	87
Appendix A -Glossary .....	89
Appendix B -Q&A .....	90
No Signal .....	90
Cannot detect SIM card .....	90
Poor Signal .....	90
IPSec VPN established, but LAN to LAN cannot communicate .....	91
Forget Router Password .....	91
Appendix C -Digital IO Scenario .....	92
Appendix D - CLI .....	93

# Chapter 1. Product Overview

## 1.1 Overview

Navigateworx NR500 series industrial cellular VPN router offers a single, flexible platform to address a variety of wireless communications needs with over-the-air configuration and system monitoring for optimal connectivity. This router enables wireless data connectivity over public and private LTE cellular networks at 4G speeds.

NR500 series router has dual SIM backup, 2 or 4 LAN ports, 1 port could be changed to Ethernet WAN connection (for fixed internet fail over to cellular). An optional 802.11 b/g/n Wi-Fi interface access point and client operations supports connectivity to IP applications in a variety of different connection scenarios. RS232 and RS485 interfaces are provided to support Serial to IP communication. NR500 series router also support 2 x digital input and 2 x Digital output for alarm applications.

NR500 series router supports 9 to 48 VDC wide range power inputs, designed with reverse-voltage protection mechanism for greater reliability. It is an advanced choice for universal wireless M2M applications with reliable features for data transmission.

## 1.2 Features and Benefits

### Industrial internet access

- Wireless Mobile Broadband 2G / 3G / 4G Connection
- Remote access to SCADA System for Industrial Automation
- Reduce high costs for on-site maintenance

### Designed for industrial usage

- Power Input Range 9 to 48 VDC
- Industrial designed for harsh environment
- Compact metal casing for easy mounting

### Secure and reliable remote connection

- Connection manager ensure seamless communication
- Support Multiple VPN tunnels for data encryption
- Firewall prevents unsafe and unauthorized access

**Easy to use and easy maintenance**

- User-friendly web interface for human interaction
- Easy configuration for deployment
- Support Web, Devices Management Platform

## 1.3 General Specifications

**Cellular Interface**

- Standards: FDD-LTE/TDD-LTE, WCDMA/UMTS/HSPA/HSPA+/EDGE/GPRS,
- 2× SMA female antenna connector
- 2 x SIM (3.0V & 1.8V)

**Wi-Fi Interface (Optional)**

- Standards: 802.11b/g/n, 300Mbps
- 2 x RP-SMA male antenna connector
- Support Wi-Fi AP and Client modes
- Security: WEP, WPA and WPA2 encryption
- Encryption: TKIP, CCMP

**Ethernet Interface**

- Standard: IEEE 802.3, IEEE 802.3u
- Number of Ports:  
NR500-Standard: 2 x 10/100 Mbps, RJ45 connector  
NR500-Pro: 4 x 10/100 Mbps, RJ45 connector
- 1 x WAN interface (configurable on Web GUI)
- 1.5KV magnetic isolation protection

**Serial Interface**

- 1×RS232 (3 PIN): TX, RX, GND
- 1 x RS485 (2 PIN): Data+(A), Data-(B)
- Baud rate: 1200bps to 921600 bps
- Connector: terminal block
- 15KV ESD protection

## DI/DO Interface

- Type: 2 x DI(dry contact) + 2 x DO(wet contact)
- Connector: terminal block
- Isolation: 3KVDC or 2KVrms
- Absolute maximum VDC: 36VDC
- Absolute maximum ADC: 100mA

## Other Interfaces

- 1× RST button
- LED instruction: 1 x SYS, 1 x NET, 1 x USR, 3 x RSSI

## Software

- Network protocols: TCP, UDP, IPv4, ICMP, NTP, DNS, HTTP, HTTPS, ARP, PPP, DHCP, IP Passthrough, VRRP
- VPN: IPsec, GRE, OpenVPN, DMVPN, L2TP, PPTP, Wireguard
- Protocol Converter: Modbus Master, Modbus Slave, Modbus ID Mapping, Modbus Gateway IEC101-104, Modbus to DNP3, DNP3 to IEC104, Modbus to SparkplugB, Modbus to LwM2M, Modbus to IEC104, DLMS Master, DLMS to IEC104, FTP Transfer, BACnet Master
- Policy: RIPv1/RIPv2/OSPF/BGP dynamic route (optional)
- Firewall & Filter: Port mapping, DMZ, 1 to1 NAT, DDos Defense
- Serial port: TCP server and client, UDP
- Management: Web, Devices Management Platform, CLI

## Power Supply and Consumption

- Connector: 3-pin 3.5 mm female socket with lock
- Input voltage range: 9~48VDC
- Power consumption:  
Idle: 100 mA@12V  
Data link: 400 mA (peak) @12V

## Physical Specification

- Ingress Protection: IP30
- Housing & Weight: Metal, 300g
- Dimension: 104mm x 104mm x 38mm (excluding antenna)
- Installations: Din-rail mounting




**Environmental**

- Operation temperature: -40~+75°C
- Store temperature: -40~+85°C
- Operation humidity: 5% to 95% non-condensing

## 1.4 Mechanical Specifications

Dimension: 106mm x 106mm x 40mm (excluding antenna)



## 1.5 Package Checklist

NR500 series Router includes the parts shown in below, please verify your components.


**NOTE:** if any of the below items is missing or damaged, please contact your sales representative.

### Included equipment


- 1 x Naviageteworx NR500 series Industrial Cellular VPN router (Wi-Fi optional)

NR500 Standard


NR500 Pro




or



- 1 x 3-pin 3.5 mm male terminal block with lock for power supply



- 1 x 10-pin 3.5 mm male terminal block for RS232/RS485/DI/DO



- 1 x Ethernet cable



- 1 x Quick Start Guide




### Optional Accessories (sold separately)

- 3G/4G cellular antenna

Stubby antenna



Magnet antenna



- RP-SMA Wi-Fi antenna


Stubby antenna




Magnet antenna



- 35mm Din-rail mounting kit



- AC/DC power adapter (12VDC, 1.5A; EU/US/UK/AU plug optional)




## 1.6 Order Information

MODEL	PN	Wi-Fi	GNSS	Frequency Bands	Description	Country
NR500-P4G	B504427	✓	✓	<b>4G:</b> LTE FDD: B1/B2/B3/B4/B5/B7/B8/B12/B13/B18/B19/B20/B25/B26/B28 LTE TDD: B38/B39/B40/B41 <b>3G:</b> UMTS: B1/B2/B4/B5/B6/B8/B19 <b>2G:</b> GSM: B2/B3/B5/B8	4G LTE, Dual SIMs, 4 x Eth, 1 x RS232 (3 PIN), 1 x RS485, 2 x DI, 2 x DO, 9 - 48VDC	Global
	B504428	✓	-	<b>4G:</b> LTE FDD: B1/B2/B3/B4/B5/B7/B8/B12/B13/B18/B19/B20/B25/B26/B28 LTE TDD: B38/B39/B40/B41 <b>3G:</b> UMTS: B1/B2/B4/B5/B6/B8/B19 <b>2G:</b> GSM: B2/B3/B5/B8	4G LTE, Dual SIMs, 4 x Eth, 1 x RS232 (3 PIN), 1 x RS485, 2 x DI, 2 x DO, 9 - 48VDC	Global
	B504429	-	-	<b>4G:</b> LTE FDD: B1/B2/B3/B4/B5/B7/B8/B12/B13/B18/B19/B20/B25/B26/B28 LTE TDD: B38/B39/B40/B41 <b>3G:</b> UMTS: B1/B2/B4/B5/B6/B8/B19 <b>2G:</b> GSM: B2/B3/B5/B8	4G LTE, Dual SIMs, 4 x Eth, 1 x RS232 (3 PIN), 1 x RS485, 2 x DI, 2 x DO, 9 - 48VDC	Global
	B504430	✓	✓	<b>4G:</b> LTE FDD: B2/B4/B5/B12/B13/B14/B66/B71 <b>3G:</b> UMTS: B2/B4/B5	4G LTE, Dual SIMs, 4 x Eth, 1 x RS232 (3 PIN), 1 x RS485, 2 x DI, 2 x DO, 9 - 48VDC	North America
	B504431	✓	-	<b>4G:</b> LTE FDD: B2/B4/B5/B12/B13/B14/B66/B71 <b>3G:</b> UMTS: B2/B4/B5	4G LTE, Dual SIMs, 4 x Eth, 1 x RS232 (3 PIN), 1 x RS485, 2 x DI, 2 x DO, 9 - 48VDC	North America
	B504432	-	-	<b>4G:</b> LTE FDD: B2/B4/B5/B12/B13/B14/B66/B71 <b>3G:</b> UMTS: B2/B4/B5	4G LTE, Dual SIMs, 4 x Eth, 1 x RS232 (3 PIN), 1 x RS485, 2 x DI, 2 x DO, 9 - 48VDC	North America
	B504433	✓	✓	<b>4G:</b> LTE FDD: B1/B3/B7/B8/B20/B28A LTE TDD: B38/B40/B41 <b>3G:</b> UMTS: B1/B8 <b>2G:</b> GSM: B3/B8	4G LTE, Dual SIMs, 4 x Eth, 1 x RS232 (3 PIN), 1 x RS485, 2 x DI, 2 x DO, 9 - 48VDC	EMEA
	B504436	✓	-	<b>4G:</b> LTE FDD: B1/B3/B7/B8/B20/B28A <b>3G:</b> UMTS: B1/B8 <b>2G:</b> GSM: B3/B8	4G LTE, Dual SIMs, 4 x Eth, 1 x RS232 (3 PIN), 1 x RS485, 2 x DI, 2 x DO, 9 - 48VDC	EMEA
	B504437	-	-	<b>4G:</b> LTE FDD: B1/B3/B7/B8/B20/B28A <b>3G:</b> UMTS: B1/B8 <b>2G:</b> GSM: B3/B8	4G LTE, Dual SIMs, 4 x Eth, 1 x RS232 (3 PIN), 1 x RS485, 2 x DI, 2 x DO, 9 - 48VDC	EMEA
	B504438	✓	-	<b>4G:</b> LTE FDD: B1/B2/B3/B4/B5/B7/B8/B28 LTE TDD: B40 <b>3G:</b> UMTS: B1/B2/B4/B5/B8 <b>2G:</b> GSM: B2/B3/B5/B8	4G LTE, Dual SIMs, 4 x Eth, 1 x RS232 (3 PIN), 1 x RS485, 2 x DI, 2 x DO, 9 - 48VDC	Latin America, Australia, New Zealand, Taiwan
	B504439	✓	-	<b>4G:</b> LTE FDD: B1/B2/B3/B4/B5/B7/B8/B28 LTE TDD: B40 <b>3G:</b> UMTS: B1/B2/B4/B5/B8 <b>2G:</b> GSM: B2/B3/B5/B8	4G LTE, Dual SIMs, 4 x Eth, 1 x RS232 (3 PIN), 1 x RS485, 2 x DI, 2 x DO, 9 - 48VDC	Latin America, Australia, New Zealand, Taiwan


# Chapter 2. Installation

## 2.1 Product Overview


### • Front Panel



### • Left Side Panel



## 2.2 LED Indicators

Name	Color	Status	Description
SYS	Green	Slow Blinking (500ms duration)	Operating normally
		Fast Blinking	System initialing
		Off	Power is off
NET	Green	On	Register to Highest priority network service (depend on Radio, e.g. Radio support LTE as Highest priority network).
		Fast Blinking (500ms duration)	Register to Non-Highest priority network service (depend on Radio, e.g. Radio support LTE as Highest priority network, then WCDMA and GPRS is non-highest priority network).
		Off	Register failed
USR: SIM	Green	On	Router is trying cellular connection with SIM1
		Fast Blinking (250ms duration)	Router is trying cellular connection with SIM2
		Off	No SIM detected
USR: Wi-Fi	Green	On	Wi-Fi is enabled but without data transmission
		Blinking	Wi-Fi is enabled and data transmission
		Off	Wi-Fi is disable or initialize failed
Signal Strength Indicator 	Green	On, 3 LED light up	Signal strength (21-31) is high
		On, 2 LED light up	Signal strength (11-20) is medium
		On, 1 LED light up	Signal strength (1-10) is low
		Off	No signal



## 2.3 Ethernet Port Indicator

Name	Status	Description
Link indicator	On	Connection is established
	Blinking	Data is being transmitted
	Off	Connection is not established

**NOTE:** There are two LED indicators for each Ethernet port. Due to the chipset design NR500 router would only light up the green one(Link indicator) on left side, the right LED is Off without meaning.

## 2.4 PIN Definition of Terminal block

- Serial Port & DIO



PIN	RS232	RS485	DI	DO	Direction
1	--	--	--	DO1	Router-->Device
2	--	--	--	DO2	Router-->Device
3	--	--	--	COM	--
4	--	A	--	--	Router<-->Device
5	--	B	--	--	Router<-->Device
6	--	--	DI1	--	Router<--Device
7	--	--	DI2	--	Router<--Device
8	GND	--	--	--	--
9	TX	--	--	--	Router-->Device
10	RX	--	--	--	Router<--Device

## • Power Input



PIN	Description
V+ (Red line)	Positive
V- (Yellow line)	Negative
PGND	GND


## 2.5 Reset Button

Function	Action
Reboot	Press the RST button within 3s under operation status
Factory Reset	Press the RST button between 3s to 10s, all LEDs blink few times then reboot the router manually.
Run Normally	Press the RST button more than 10s, router will run normally without reboot or factory reset.

## 2.6 Insert SIM card


### • Insert / Remove SIM card

1. Make sure the power is disconnected.
2. Use a Phillips-head screwdriver to remove SIM slot cover.
3. Insert the SIM card(s) in to the SIM sockets.
4. Replace the SIM slot cover.




## 2.7 Install Antenna

- Connect the cellular antenna to the MAIN and AUX connector on the unit.





**NOTE:** NR500 router supports dual antennas with MAIN and AUX connectors. MAIN connector is for data receiving and transmission. AUX connector is for enhancing signal strength, which cannot be used separately.

- Connect the Wi-Fi antenna to the Wi-Fi connector on the unit.




## 2.8 DIN-rail Mounting

1. Use 4 pcs of M3x6 flat head phillips screws to fix the DIN-rail to the router.
2. Insert the upper lip of the DIN-rail into the DIN-rail mounting kit.
3. Press the router towards the DIN-rail until it snaps into place.



## 2.9 Protective Grounding Installation


1. Remove the grounding nut.
2. Connect the grounding ring of the cabinet's grounding wire onto the grounding stud and screw up the grounding nut.



**NOTE:** Strongly recommended the router to be grounded when deployed.


## 2.10 Power Supply Installation

1. Remove the pluggable connector from the unit, then loosen the screws for the locking flanges as needed.
2. Connect the wires of the power supply to the terminals.



## 2.11 Power On The Router

1. Connect one end of the Ethernet cable to the LAN port on the unit and the other end to a LAN port on a PC.
2. Connect the AC power to a power source.
3. Router is ready when SYS LED is blinking.



# Chapter 3. Access to Web page


## 3.1 PC Configuration

NR500 router contains a DHCP server which will automatically assign an IP address to your PC, however in some cases the user may need to change the network settings on their PC to accept the IP address from the NR500. or you can configure a static IP address manually.

- **Obtain an IP address automatically**


The process required to do this differs depending on the version of Windows you are using.

**NOTE:** The following steps are based on Windows 7.



select **Start » Control Panel » Network Connections**. Right click **Local Area Connection** and select **Properties** to open the configuration dialog box for Local Area Connection. Select **Internet Protocol (TCP/IP)** and click **Properties** to open the TCP/IP configuration window. On the General tab, select **Obtain an IP address automatically** and **Obtain DNS server address automatically**. Click **OK** to complete TCP/IP configuration.

- **Set to a static IP address**



click "**Use the following IP address**" to assign a static IP manually within the same subnet of the router.

**NOTE:** *Default gateway* and *DNS server* is not necessary if PC not routing all traffic go through NR500 router.

## 3.2 Factory Default Settings

NR500 router supports Web-based configuration interface for management. If this is the first time for you to configure the router, please refer to below default settings.

Username: **admin**


Password: **admin**

LAN IP Address: **192.168.5.1** (Eth0~Eth1/Eth3 bridge as LAN mode)

DHCP Server: **Enabled**

### 3.3 Login to Web Page

1. Start a Web browser on your PC (Chrome and IE are recommended), enter 192.168.5.1 into the address bar of the web browser.
2. Then use the default username and password(admin/admin), to log in to the router.





# Chapter 4. Web Configuration

## 4.1 Web Interface

The NR500 router Web interface is divided into two sections. In the left pane is the main navigation menu. On the right is the content area for each page.



**NOTE:** The navigation menu may contain fewer sections than shown here depending on which options are installed in your unit.

- **Reboot:** reset the router within power disconnect.
- **Logout:** logout to web authorization page.



- **Save:** save the configuration on current page.
- **Apply:** apply the changes on current page immediately.



- **Close:** exit without changing the configuration on current page.



## 4.2 Overview

### 4.2.1 Status

You can view the system information of the router on this page.

Status		
System Information		
Device Model	NR500-v2-P4G	
System Uptime	00:01:36	
System Time	2023-07-17 16:30:55 	
RAM Usage	67M Free/0M Shared/128M Total	
Firmware Version	3.0.0 (fa20ec1-1)	
Kernel Version	4.4.60	
Serial Number	23075147330001	

#### System Information

- **Device Model**  
Displays the model name of router
- **System Uptime**  
Displays the duration the system has been up in hours, minutes and seconds.
- **System Time**  
Displays the current date and time.
- **RAM Usage**  
Displays the RAM capacity and the available RAM memory.
- **Firmware Version**  
Displays the current firmware version of router.
- **Kernel Version**  
Displays the current kernel version of router.
- **Serial Number**  
Display the serial number of router.

Active Link Information		
	Link Type	WWAN1
	IP Address	10.252.90.234
	Netmask	255.255.255.252
	Gateway	10.252.90.233
	Primary DNS Server	120.80.80.80
	Secondary DNS Server	221.5.88.88

Active Link Information

- **Link Type**  
Current interface for internet access.
- **IP Address**  
Displays the IP address assigned to this interface.
- **Netmask**  
Displays the subnet mask of this interface.
- **Gateway**  
Displays the gateway of this interface. This is used for routing packets to remote networks.
- **Primary DNS Server**  
Displays the primary DNS server of this interface.
- **Secondary DNS Server**  
Displays the secondary DNS server of this interface.

## 4.2.2 Syslog

Syslog
Events

**Syslog Information**

```

Jul 14 10:43:53 navigatworx user.debug syslog: [07-14_10:43:53:456] Get clientDMS = 1
Jul 14 10:43:53 navigatworx user.debug syslog: [07-14_10:43:53:488] Get clientNAS = 4
Jul 14 10:43:53 navigatworx user.debug syslog: [07-14_10:43:53:522] Get clientUIM = 1
Jul 14 10:43:53 navigatworx user.debug syslog: [07-14_10:43:53:553] Get clientWDA = 1
Jul 14 10:43:53 navigatworx user.debug syslog: [07-14_10:43:53:585] requestBaseBandVersion EC25EFAR06A03M4G
Jul 14 10:43:53 navigatworx user.debug syslog: [07-14_10:43:53:713] requestGetSIMStatus SIMStatus: SIM_READY
Jul 14 10:43:53 navigatworx user.debug syslog: [07-14_10:43:53:713] requestSetProfile[1] 3gnet///0
Jul 14 10:43:53 navigatworx user.debug syslog: [07-14_10:43:53:777] requestGetProfile[1] 3gnet///0
Jul 14 10:43:53 navigatworx user.debug syslog: [07-14_10:43:53:809] requestRegistrationState2 MCC: 460, MNC: 1, PS: Attached, DataCap: LTE
Jul 14 10:43:53 navigatworx user.debug syslog: [07-14_10:43:53:842] requestQueryDataCall IPv4ConnectionStatus: DISCONNECTED
Jul 14 10:43:53 navigatworx user.debug syslog: [07-14_10:43:53:872] requestSetupDataCall WdsConnectionIPv4Handle: 0x87348c00
Jul 14 10:43:54 navigatworx user.debug syslog: [07-14_10:43:54:032] IPv4 MTU = 1500
Jul 14 10:43:54 navigatworx user.notice connection_manager: quectel session trigger connect
Jul 14 10:43:54 navigatworx user.debug connection_manager[3223]: modem is ready, ifname=wwan1 sim=1
Jul 14 10:43:54 navigatworx user.debug connection_manager[3223]: start dhcp for wwan1
Jul 14 10:43:54 navigatworx daemon.err udhcpc[3244]: started, v1.25.1
Jul 14 10:43:54 navigatworx daemon.err udhcpc[3244]: sending discover
Jul 14 10:43:54 navigatworx daemon.err udhcpc[3244]: sending select for 10.252.90.234
Jul 14 10:43:54 navigatworx daemon.err udhcpc[3244]: lease of 10.252.90.234 obtained, lease time 7200
Jul 14 10:43:54 navigatworx user.debug udhcpc: dhcp get configuration of wwan1
Jul 14 10:43:54 navigatworx user.debug connection_manager[3223]: wwan1 is connected
Jul 14 10:43:54 navigatworx user.debug connection_manager[3223]: setup active link wwan1
Jul 14 10:43:54 navigatworx daemon.info dnsmasq[2048]: reading /etc/resolv.conf
Jul 14 10:43:54 navigatworx daemon.info dnsmasq[2048]: using nameserver 120.80.80.80#53
Jul 14 10:43:54 navigatworx daemon.info dnsmasq[2048]: reading /etc/resolv.conf
Jul 14 10:43:54 navigatworx daemon.info dnsmasq[2048]: using nameserver 120.80.80.80#53
Jul 14 10:43:54 navigatworx daemon.info dnsmasq[2048]: using nameserver 221.5.88.88#53
Jul 14 10:43:54 navigatworx user.debug connection_manager: update route of wwan1 successful
Jul 14 10:43:55 navigatworx user.debug connection_manager[3223]: start ICMP detecting(wwan1->8.8.8.8/114.114.114.114)
Jul 14 10:43:56 navigatworx user.debug connection_manager[3223]: WWAN1 ICMP detecting success
          
```

Download Diagnosis
Download Syslog
Clear
Refresh

### Syslog Information

- **Download Diagnosis**  
Download the Diagnosis file for analysis.
- **Download Syslog**  
Download the complete syslog since last reboot.
- **Clear**  
Clear the current page syslog printing.
- **Refresh**  
Reload the current page with latest syslog printing.

## 4.3 Link Management

This section shows you the setup of link management.

### 4.3.1 Connection Manager

<u>Status</u>		Connection				
Connection Information						
Index	Type	Status	IP Address	Netmask	Gateway	Uptime
1	WWAN1	Connected	10.252.90.234	255.255.255.252	10.252.90.233	00:01:09
2	WWAN2	Disconnected				

#### Connection Manager->Status

- **Type**  
Displays the connection interface
- **Status**  
Displays the connection status of this interface.
- **IP Address**  
Displays the IP Address of this interface.
- **Netmask**  
Displays the subnet mask of this interface.
- **Gateway**  
Displays the gateway of this interface. This is used for routing packets to remote networks.

Status		Connection	
General Settings			
Priority	Enable	Connection Type	Description
1	true	WWAN1	
2	true	WWAN2	



Click to add a new priority interface.



Click to edit current interface settings.



Click to delete current interface.

#### Connection Manager->Connection

- **Priority**  
Displays the priority list of default routing selection.
- **Enable**  
Displays the connection enable status.

- **Connection Type**  
Displays the name of this interface.
- **Description**  
Displays the description of this connection.

Connection Settings	
<b>General Settings</b>	
Priority	<input type="text" value="1"/>
Enable	<input checked="" type="checkbox"/>
Connection Type	<input type="text" value="WWAN1"/> ?
Description	<input type="text"/>
NAT Enable	<input checked="" type="checkbox"/>
Connection Retry Times	<input type="text" value="3"/> ?
Override MTU	<input type="text"/>
<b>ICMP Detection Settings</b>	
Enable	<input checked="" type="checkbox"/>
Primary Server	<input type="text" value="8.8.8.8"/>
Secondary Server	<input type="text" value="114.114.114.114"/>
Interval	<input type="text" value="300"/> ?
Retry Interval	<input type="text" value="5"/> ?
Timeout	<input type="text" value="3"/> ?
Retry Times	<input type="text" value="3"/> ?
<input type="button" value="Save"/> <input type="button" value="Close"/>	

## Connection Settings

- **Priority**  
Displays current index on priority list.
- **Connection Type**  
Select the available interface as outbound link.  
**NOTE:** specify SIM1 carrier link as WWAN1, SIM2 carrier link as WWAN2.
- **NAT Enable**  
Check this box to enable NAT (Network Address Translation) on the current link.
- **Connection Retry Times**  
Specify Retry Times for the whole ICMP detection.
- **Override MTU**  
Specify a MTU to override the MTU on current link. MTU is the maximum length of a data packet that can be transmitted on a network, in bytes.

- **ICMP Detection Settings->Enable**

Check this box to detect link connection status based on pings to a specified IP address.

- **Primary Server**

Enter the primary IP address that pings will be sent to, to detect the link state. Recommend entering the IP address of known external reachable server or network (e.g. 8.8.8.8).

- **Secondary Server**

Enter the secondary IP address that pings will be sent to, when the primary server is ping failed, router would try to ping the secondary server.

- **Interval**

The duration of each ICMP detection in seconds.

- **Retry Interval**

The interval in seconds between each ping if no packets have been received.

- **Timeout**

Enter timeout for received ping reply to determine the ICMP detection failure.

- **Retry Times**

Specify the retry times for ICMP detection.



## 4.3.2 Cellular

NR500 Router main function is connecting to Internet by cellular modem.

Status

Cellular

Cellular Information

Index	Modem	Registration	CSQ	Operator	Network Type	IMEI	IMSI	TX Bytes	RX Bytes
1	EC25	Registered	Medium(14,-8...	CHN-UNICOM	LTE	866758044670095	460014495060406	516.37 KB	581.94 KB
			Index	1					
			Modem	EC25					
			Registration	Registered					
			CSQ	Medium(14,-85dBm)					
			Operator	CHN-UNICOM					
			Network Type	LTE					
			IMEI	866758044670095					
			PLMN ID	46001					
			Local Area Code	25DB					
			Cell ID	60F9715					
			IMSI	460014495060406					
			MSISDN						
			TX Bytes	516.37 KB					
			RX Bytes	581.94 KB					
			Modem Firmware	EC25EFAR06A03M4G					

### Cellular->Status

- **Modem**  
Displays the module of the modem used by this WWAN interface.
- **Registration**  
Displays the registration status of SIM card.
- **CSQ**  
Displays the signal strength of the carrier network.
- **Operator**  
Displays the wireless network provider.
- **Network Type**  
Displays the RF technology currently active. Example: LTE, UMTS, or CDMA.
- **IMEI**  
International Mobile Electronic Identifier. Depending on the carrier and technology used, this may be required for the carrier when activating the data contract. In some cases this will be blank.
- **PLMN ID**  
Displays the current PLMN ID, including MCC, MNC, LAC and Cell ID.

- **Local Area Code**  
Displays the location area code of the SIM card.
- **Cell ID**  
Displays the Cell ID of the SIM card location.
- **IMSI**  
International Mobile Subscriber Identity, as read from the SIM. This is the user's network subscription.
- **MSISDN**  
Display the current MSISDN of this cellular connection. MSISDN is a number uniquely identifying a subscription in a Global System for Mobile communications.
- **TX Bytes**  
Displays the total bytes transmitted since the time the unit was connected. NR500 router would record this data with same SIM card, reboot would not erase this data.
- **RX Bytes**  
Displays the total bytes received since the time the unit was connected. NR500 router would record this data with same SIM card, reboot would not erase this data.
- **Modem Firmware**  
Displays firmware version of the module used by the WWAN interface.

Status		Cellular
Modem General Settings		
Index	SIM Card	Auto APN
1	SIM1	true
2	SIM2	true

Cellular

- **SIM Card**  
Displays the SIM card support on this unit.
- **Auto APN**  
Displays the Enable status of auto APN function.

**SIM Card Settings**

**Modem General Settings**

Index	<input type="text" value="1"/>	
SIM Card	<input type="text" value="SIM1"/>	
CID	<input type="text" value="1"/>	
MSISDN	<input type="text"/>	
Auto APN	<input checked="" type="checkbox"/>	
Dial Number	<input type="text" value="*99#"/>	
Authentication Type	<input type="text" value="Auto"/>	
PIN Code	<input type="text"/>	?
Monthly Data Limitation	<input type="text" value="0"/>	?
Monthly Billing Day	<input type="text" value="1"/>	?
Enable VoLTE	<input checked="" type="checkbox"/>	
Data Roaming	<input checked="" type="checkbox"/>	
Override Primary DNS	<input type="text"/>	
Override Secondary DNS	<input type="text"/>	
Expert Options	<input type="text"/>	?

**Modem Network Settings**

Network Type	<input type="text" value="Auto"/>	
Enable Network Selection	<input type="checkbox"/>	
Use All Bands	<input checked="" type="checkbox"/>	

## SIM Card Settings

- **SIM Card**  
Displays the current SIM card settings.
- **CID**  
Specify CID of the current SIM card supported by the carrier.
- **Auto APN**  
Check this box enable auto checking the Access Point Name provided by the carrier.
- **Dial Number**  
Enter the dial number of the carrier.
- **Authentication Type**  
Authentication method used by the carrier. Possible selections are Auto, PAP, CHAP.
- **PIN Code**  
Enter a 4-8 characters PIN code to unlock the SIM.
- **Monthly Data Limitation**  
Enter the data total amount for SIM card, SIM card switchover when data reach limitation.
- **Monthly Billing Day**  
Enter the date of renew data amount every month.

- **Data Roaming**  
Enable or disable the data roaming function on the router.
- **Enable VoLTE**  
Enable or disable the VoLTE function on the router.
- **Override Primary DNS**  
Enter the primary DNS server will override the automatically obtained DNS.
- **Override Secondary DNS**  
Enter the secondary DNS server will override the automatically obtained DNS.
- **Network Type**  
Select the mode of operation of the cell module (Auto, 4G Firstly, 4G Only, etc.).
- **Use All Bands**  
Check this box to enable all bands selection or choose specified bands.

### 4.3.3 Ethernet

The same instructions apply to settings for all Ethernet interfaces.

Status	Port Assignment	WAN	LAN	VLAN
<b>Ethernet Port Information</b>				
Index	Name	Status		
1	ETH0	Down		
2	ETH1	Down		
3	ETH2	Up		
4	ETH3	Down		
<b>Interface Information</b>				
Index	Name	MAC Address		
1	wan	00:12:AF:40:30:0C		
2	lan0	00:12:AF:40:30:0D		
<b>DHCP Lease Table</b>				
Index	MAC Address	IP Address	Lease Expires	Hostname
1	80:fa:5b:20:79	192.168.5.2	2023-07-14 15:37:33	PC201911121117L

#### Ethernet->Status

- **Ethernet Port Information**  
Displays the port physical connected states.
- **Interface Information**  
Displays the name and MAC address of Ethernet interface.
- **DHCP Lease Table**  
Displays the current IP address assigned to DHCP client.

Status	Port Assignment	WAN	LAN	VLAN
<b>General Settings</b>				
Index	Port	Interface		
1	Eth0	WAN		
2	Eth1	LAN0		
3	Eth2	LAN0		
4	Eth3	LAN0		

#### Ethernet->Port Assignment

- **Port**  
Displays the port states and numbers of this unit.
- **Interface**  
Displays the port states of belong subnet.

Port Settings	
General Settings	
Index	<input type="text" value="1"/>
Port	<input type="text" value="Eth0"/>
Interface	<input type="text" value="WAN"/>
<input type="button" value="Save"/> <input type="button" value="Close"/>	

*Note: Please make sure LAN0 is assigned and existing.*

### Ethernet->Port Settings

- **Port**  
Indicate the current configure port.
- **Interface**  
Select belong subnet for current configure port.

Status	Port Assignment	WAN	LAN	VLAN
<b>General Settings</b>				
		Connection Type	<input type="text" value="DHCP"/>	
<b>Advanced Settings</b>				
		MTU	<input type="text" value="1500"/>	
		Override Primary DNS	<input type="text"/>	
		Override Secondary DNS	<input type="text"/>	
<b>Secondary Wan Settings</b>				
Index	IP Address	Netmask		

### Ethernet->WAN

- **Connection Type**  
If you select DHCP Client, external DHCP server will assign an IP address to this unit.
- **MTU**  
Maximum Transmission Unit, maximum packet size allowed to be transmitted. Should be left as default value of 1500 in most cases.
- **Override Primary DNS**  
Enter the primary DNS server will override the automatically obtained DNS.
- **Override Secondary DNS**  
Enter the secondary DNS server will override the automatically obtained DNS.

### Ethernet->WAN->Secondary Wan Settings




- **IP Address**  
Enter the IP address of secondary wan interface.
- **Netmask**  
Enter the netmask of secondary wan interface.

NR500 also support WAN connection type set to Static IP and PPPoE mode.

Status	Port Assignment	WAN	LAN	VLAN
<b>General Settings</b>				
		Connection Type	Static IP ▼	
		IP Address	<input type="text"/>	
		Netmask	<input type="text"/>	
		Gateway	<input type="text"/>	
		Primary DNS	<input type="text"/>	
		Secondary DNS	<input type="text"/>	
<b>General Settings</b>				
		Connection Type	PPPoE ▼	
		Authentication Type	Auto ▼	
		Username	<input type="text"/>	
		Password	<input type="text"/>	

### Ethernet->WAN->Static IP or PPPoE

- **IP Address**  
Static address for this interface. It must be on the same subnet as the gateway.
- **Netmask**  
Will be assigned by the gateway.
- **Gateway**  
IP address of the Gateway (DHCP Host). If not known this can be left as all zeros.
- **Primary DNS**  
IP address of the primary DNS server.
- **Secondary DNS**  
IP address of the secondary DNS server.
- **Authentication Type**  
Authentication method used by the carrier. Possible selections are Auto, PAP, CHAP.
- **Username**  
Username to provide when connecting.
- **Password**  
Password to provide when connecting.

Status	Port Assignment	WAN	LAN	VLAN
<b>General Settings</b>				
Index	Interface	IP Address	Netmask	
1	LAN0	192.168.5.1	255.255.255.0	 
<b>Multiple IP Settings</b>				
Index	Interface	IP Address	Netmask	
				

Ethernet->LAN

- **Interface**  
Displays current name of LAN subnet.
- **IP Address**  
Displays LAN IP address of this subnet.
- **Netmask**  
Displays subnet mask for this subnet.

LAN Settings

General Settings

Index

1

Interface

LAN0

IP Address

192.168.5.1

Netmask

255.255.255.0

MTU

1500

DHCP Settings

Enable

☒

Mode

Server

IP Pool Start

192.168.5.2

IP Pool End

192.168.5.200

Netmask

255.255.255.0

Lease Time

120

?

Gateway

Primary DNS

Secondary DNS

WINS Server

DHCP Settings

Enable

☒

Mode

Relay

Relay Server

Save

Close

Ethernet->LAN

- **Interface**  
Select the configurate LAN port of this subnet.
- **IP Address**  
Enter LAN IP address for this interface.
- **Netmask**  
Enter subnet mask for this subnet.



- **MTU**  
Maximum Transmission Unit, maximum packet size allowed to be transmitted. Should be left as default value of 1500 in most cases.
- **Enable**  
Check this box to enable DHCP feature on current LAN port.
- **Mode**  
Select the DHCP working mode from "Server" or "Relay".
- **Relay Server**  
Enter the IP address of DHCP relay server.
- **IP Pool Start**  
External LAN devices connected to this unit will be assigned IP address in this range when DHCP is enabled. This is the beginning of the pool of IP addresses.
- **IP Pool End**  
This is the end of the pool of IP addresses.
- **Netmask**  
Subnet mask of the IP address obtained by DHCP clients from DHCP server.
- **Lease Time**  
The lease time of the IP address obtained by DHCP clients from DHCP server.
- **Gateway**  
The gateway address obtained by DHCP clients from DHCP server.
- **Primary DNS**  
Primary DNS server address obtained by DHCP clients from DHCP server.
- **Secondary DNS**  
Secondary DNS server address obtained by DHCP clients from DHCP server.
- **WINS Server**  
Windows Internet Naming Service obtained by DHCP clients from DHCP server.

MAC Binding IP Settings	
MAC Binding IP Settings	
Index	1
Enable	<input checked="" type="checkbox"/>
Description	<input type="text"/>
Host MAC Address	<input type="text"/> ?
Host IP Address	<input type="text"/>
<input type="button" value="Save"/> <input type="button" value="Close"/>	

#### Ethernet->LAN->MAC Binding IP Settings

- **Enable**  
Check this box to enable MAC binding IP feature.
- **Description**  
Enter the description for MAC binding IP feature.

- **Host MAC Address**  
Enter the host MAC address.
- **Host IP Address**  
Enter the host IP address.

Multiple IP Settings	
General Settings	
Index	<input type="text" value="1"/>
Interface	<input type="text" value="LAN0"/>
IP Address	<input type="text"/>
Netmask	<input type="text"/>
<input type="button" value="Save"/> <input type="button" value="Close"/>	

### Ethernet->LAN->Multiple IP Settings

- **Interface**  
Select the configurate LAN port of this subnet.
- **IP Address**  
Enter multiple IP address for this interface.
- **Netmask**  
Enter subnet mask for this subnet.

Trunk Settings	
VLAN Trunk Settings	
Index	<input type="text" value="1"/>
Interface	<input type="text" value="LAN0"/>
VID	<input type="text" value="10"/>
IP Address	<input type="text"/>
Netmask	<input type="text"/>
<input type="button" value="Save"/> <input type="button" value="Close"/>	

### Ethernet->VLAN->VLAN Trunk Settings

- **Interface**  
Select the LAN port for VLAN trunk.
- **VID**  
Specify the VLAN ID for VLAN trunk.
- **IP Address**  
Enter IP address for this VLAN trunk.
- **Netmask**  
Enter subnet mask for this VLAN trunk.

### 4.3.4 Wi-Fi

NR500 router could only be set to function as either a Wi-Fi Client or a Wi-Fi Access Point, but not both simultaneously. Select Wi-Fi (Access Point) from the main navigation menu to Wi-Fi (default as Access Point) page, which contains tabs for configuration of the Wi-Fi Access Point interface. You could review the Wi-Fi connection status as below.

StatusBasicWiFi AP

WiFi Status

StatusReady

SSIDNR500-WAN

MAC Addressa8:3f:a1:e0:ab:81

Current Channel6

Channel Width40 MHz

TX Power20.00 dBm

Associated Station

Index	MAC Address	Signal	Station Name
1	30:59:b7:16:3b:66	-55 dBm	KEN-COMPUTER
2	98:10:e8:67:dd:35	-64 dBm	iPhone

StatusBasicWiFi AP

Basic Settings

Running ModeAP

Country CodeCN

Wi-Fi->Basic

- Running Mode**  
Select the configurate Wi-Fi mode from AP or Client.
- Country Code**  
Enter the country where the AP is located.

## Wi-Fi AP

Wi-Fi AP settings page as below.

The screenshot shows the 'WiFi AP' settings page. At the top, there are three tabs: 'Status', 'Basic', and 'WiFi AP'. The 'WiFi AP' tab is selected. Below the tabs is a header 'WiFi AP Settings'. The settings are organized into two main sections: 'WiFi AP Settings' and 'Advanced Settings'. In the 'WiFi AP Settings' section, 'Enable' is checked, 'SSID' is 'wifi-a-p', 'Enable Broadcast SSID' is checked, 'Security Mode' is 'WPA PSK', 'WPA Type' is 'WPA2', 'Encryption Type' is 'Auto', and 'Password' is empty. In the 'Advanced Settings' section, 'Channel' is 'Auto', 'Wireless Mode' is '802.11bgn', 'Channel Width' is '40 MHz', 'Beacon TX Rate HT MCS Index' is 'Auto', 'TX Power' is 'High', 'Beacon Interval' is '100', 'DTIM Period' is '100', 'Max Client Support' is '32', 'Enable Short GI' is checked, and 'Enable AP Isolate' is unchecked. At the bottom right, there are 'Save' and 'Apply' buttons.

### Wi-Fi->Wi-Fi AP

- **Enable**  
Check this box will enable the Wireless interface.
- **SSID**  
The SSID is the name of the wireless local network. Devices connecting to the NR500 router WiFi access will identify the Access Point by this SSID.
- **Enable Broadcast SSID**  
When the checkbox is not checked, SSID broadcast is disabled, other wireless devices can't not find the SSID, and users have to enter the SSID manually to access to the wireless network.
- **Security Mode**  
Select security mode from "None", "WEP" or "WPA PSK".
- **WPA Type**  
Select WPA Type from "Auto", "WPA" and "WPA2".
- **Encryption Type**  
Select the encryption method. Options are "Auto", "TKIP", or "CCMP". Because these options depend on the authentication method selected, some options will not be available.
- **Password**  
Enter the pre-shared key of WEP/WPA encryption.

- **Channel**

Select the Wi-Fi channel the module will transmit on. If there are other Wi-Fi devices in the area the NR500 router should be set to a different channel than the other access points. Channels available for selection depend on the selected Band.

- **Wireless Mode**

Select the Wi-Fi 802.11 mode: B, G, or N. Available selections depend on selected Band.

- **Channel Width**

Select the width of the Wi-Fi channel. 20 MHz will limit the channel to 20 MHz wide; 20/40 MHz will enable the use of a 40 MHz wide channel when available.

- **Beacon TX Rate HT MCS Index**

Modulation and Coding Scheme, The MCS modulation coding table is a representation proposed by 802.11n to characterize the communication rate of the WLAN. The MCS takes the factors affecting the communication rate as the columns of the table and uses the MCS index as a row to form a rate table.

- **TX power**

Select the transmission power for the AP from "High", "Medium" and "Low".

- **Beacon Interval**

Enter the interval of time in which the router AP broadcasts a beacon which is used for wireless network authentication.

- **DTIM Period**

Enter the delivery traffic indication message period and the router AP will multicast the data according to this period.

- **Max Client Support**

Enter the maximum number of clients to access when the router is configured as AP.

- **Enable Short GI**

Check this box to enable Short GI(guard interval), Short GI is a blank time between two symbols, providing a long buffer time for signal delay.

- **Enable AP Isolate**

Check this box to enable AP isolate, the route will isolate all connected wireless devices.

## Wi-Fi Client

Wi-Fi Client settings page as below.

Status	Basic	WiFi Client
<b>WiFi Client Settings</b>		
	Enable	<input checked="" type="checkbox"/>
	Connect to Hidden SSID	<input type="checkbox"/>
	SSID	<input type="text"/>
	Password	<input type="text"/>
<b>IP Address Settings</b>		
	Connection Type	<input type="text" value="DHCP"/>

<b>Status</b>	<b>Basic</b>	<b>WiFi Client</b>
---------------	--------------	--------------------

**WiFi Client Settings**

Enable	<input checked="" type="checkbox"/>
Connect to Hidden SSID	<input type="checkbox"/>
SSID	<input type="text"/>
Password	<input type="text"/>

**IP Address Settings**

Connection Type	Static IP ▾
IP Address	<input type="text"/>
Netmask	<input type="text"/>
Gateway	<input type="text"/>
Primary DNS	<input type="text"/>
Secondary DNS	<input type="text"/>

## Wi-Fi->Wi-Fi Client

- **Enable**  
Check this box will enable the Wireless interface.
- **Connect to Hidden SSID**  
Check this box will enable connect to hidden SSID.
- **SSID**  
The SSID of external access point.
- **Password**  
Enter the password of external access point.
- **Connection Type**  
Select from DHCP Client or Static IP address.
- **IP Address**  
Static address for this interface. It must be on the same subnet as the gateway.
- **Netmask**  
Will be assigned by the gateway.
- **Gateway**  
IP address of the Gateway.
- **Primary DNS**  
Enter the primary DNS server will override the automatically obtained DNS.
- **Secondary DNS**  
Enter the secondary DNS server will override the automatically obtained DNS.



- **Remote port**  
Displays the Remote port number of the current COM1/2 connection.
- **Connection status**  
Dispalys the status of current COM1/2 connection.

Status	<u>Connection</u>					
Serial Connection Settings						
Index	Enable	Port	Baud Rate	Data Bits	Stop Bits	Parity
1	false	COM1	115200	8	1	None
2	false	COM2	115200	8	1	None

Serial->Connection

- **Enable**  
Displays status of current serial function.
- **Port**  
Displays the serial type of COM port.
- **Baud Rate**  
Displays the serial port baud rate.
- **Data Bits**  
Displays the serial port Data Bits.
- **Stop Bits**  
Displays the serial port Stop Bits.
- **Parity**  
Displays the serial port parity.



Connection Settings			
Serial Connection Settings			
Index	1		
Enable	<input type="checkbox"/>		
Port	COM1		
Baud Rate	115200		
Data Bits	8		
Stop Bits	1		
Parity	None		
Response Timeout	1000 ?		
Transmission Settings			
Transmission Method	Transparent		
MTU	1024 ?		
Protocol	TCP Client		
TCP Client/UDP Channel			
Index	Remote Address	Remote Port	+

Save
Close

### Serial->Connection Settings

- Baud Rate**  
 Select the serial port baud rate. Supported values are 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400, 460800 or 921600.
- Data Bits**  
 Select the values from 8.
- Stop Bits**  
 Select the values from 1 or 2.
- Parity**  
 Select values from none, even, odd.
- Transmission Method**  
 Select the transmission method for serial port. Optional for "Transparent", "Modbus RTU Gateway" and "Modbus ASCII Gateway".
- MTU**  
 Maximum Transmission Unit, maximum packet size allowed to be transmitted. Should be left as default value of 1024 in most cases.
- Protocol**  
 Select the mode for Serial IP communication. Supported modes are UDP, TCP Server, or TCP Client. Above window displays these settings when you select **TCP Client** on Protocol.
- Remote Address**  
 Enter the IP address of the remote server.
- Remote Port**  
 Enter the port number of the remote server.

Serial->Connection Settings

- **Remote Address**  
Enter the IP address of the remote server.
- **Remote Port**  
Enter the port number of the remote server.

When you select **TCP Server** on Protocol, the window displays the settings as below.

Transmission Settings

Transmission Method

Transparent

▼

MTU

1024

?

Protocol

TCP Server

▼

Local IP Address

Local Port

2000

Server Accept Mode

Close Existing

▼

Save

Close

Serial->Connection Settings

- **Local IP Address**  
Enter the IP Address of the local endpoint.
- **Local Port**  
The port number assigned to the serial IP port on which communications will take place.
- **Server Accept Mode**  
Select the Server accept mode. Selections are "Close Existing" and "Close New".

When you select **UDP** on Protocol, the window displays the settings as below.

Transmission Settings

Transmission Method

Transparent

▼

MTU

1024

?

Protocol

UDP

▼

Local IP Address

Local Port

2000

TCP Client/UDP Channel

Index

Remote Address

Remote Port

+

Save

Close

## Serial->Connection Settings

- **Local IP Address**  
Enter the IP Address of the local endpoint.
- **Local Port**  
The port number assigned to the serial IP port on which communications will take place.
- **Remote Address**  
Enter the IP address of the remote server.
- **Remote Port**  
Enter the port number of the remote server.

## 4.4.2 Digital IO

This section allows you to set the Digital IO parameters. The Digital input could be used for triggering alarm, and Digital output could be used for controlling the slave device by digital signal. You could review the status of Digital IO as below.

Status	Digital IO	Counter Ctrl		
Digital Input Information				
Index	Enable	Logic Level	Status	Counter
1	false	High	Alarm OFF	0
2	false	High	Alarm OFF	0
Digital Output Information				
Index	Enable	Logic Level	Status	
1	false	Low	Alarm OFF	
2	false	Low	Alarm OFF	

### Digital IO->Status

- **Enable**  
Displays status of current digital IO function.
- **Logic Level**  
Displays the electrical level of digital IO port.
- **Status**  
Displays the alarm status of digital IO port.
- **Counter**  
Display the number of digital input port counters.

Digital Input

Digital Input Settings

Index

1

Enable
☐

Alarm ON Mode

Low

Alarm ON Content

?

Alarm OFF Content

?

Save

Close

### Digital IO->Digital Input

- **Enable**  
Check this box to enable digital Input function.
- **Alarm ON Mode**  
Select the electrical level to trigger alarm. Option are "Low" and "High".

- **Alarm ON Content**

Specify the alarm on content to be sent out via SMS message.

- **Alarm OFF Content**

Specify the alarm off content to be sent out via SMS message.

Digital Output	
Digital Output Settings	
Index	1
Enable	<input type="checkbox"/>
Alarm Source	DI1
Alarm ON Action	High
Alarm OFF Action	Low
<div>Save Close</div>	

## Digital IO->Digital Output

- **Enable**

Check this box to enable digital output function.

- **Alarm Source**

Select from "DI1", "DI2" or "SMS". Digital output triggers the related action when there is alarm comes from Digital Input or SMS.

- **Alarm ON Action**

Select from "High", "Low" or "Pulse". High means high electrical level output. Low means low electrical level output. Pulse will generate a square wave as specified in the pulse mode parameters when triggered.

- **Alarm OFF Action**

Initiates when alarm disappeared. Select from "High", "Low" or "Pulse". High means high electrical level output. Low means low electrical level output. Pulse will generate a square wave as specified in the pulse mode parameters when triggered.

- **Pulse Width**

This parameter is available when select "Pulse" as "Alarm ON Action/Alarm OFF Action". The selected digital output channel will generate a square wave as specified in the pulse mode parameters.

Status	Digital IO	Counter Ctrl
Counter Ctrl		
ID	1	
Count		

## Counter Ctrl

- **ID**

Select serial connection Index, 1 or 2.

- **Count**

Set the number of digital input port counters by manually.

# 4.5 Network

## 4.5.1 Firewall

Firewall rules are security rule-sets to implement control over users, applications or network objects in an organization. Using the firewall rule, you can create blanket or specialized traffic transit rules based on the requirement.

ACL

Port Mapping

DMZ

NAT

URL Filter

General Settings

Default Policy

Accept

ACL Rule Settings

Index	Description	Chain	Protocol	Source Address	Source Port	Destination Address	Destination Port	
-------	-------------	-------	----------	----------------	-------------	---------------------	------------------	--

Firewall->ACL

- Default Policy

Select the "Accept" or "Drop" from the list, the packets which are not included in the access control list will be processed by the default filter policy.

An access control list (ACL), with respect to a computer file system, is a list of permissions attached to an object. An ACL specifies which users or system processes are granted access to objects, as well as what operations are allowed on given objects.

ACL Settings

ACL Rule Settings

Index

1

Description

Chain

FORWARD

Protocol

All

Source Address

Destination Address

?

?

Save

Close

## Firewall->ACL

- **Description**  
Add a description for this rule.
- **Chain**  
Specify the forward rule of ACL, choose from "FORWARD" and "INPUT".
- **Protocol**  
All: Any protocol number.  
TCP: The TCP protocol.  
UDP: The UDP protocol.  
TCP & DUP: both TCP and UDP protocol  
ICMP: The ICMP protocol.  
GRE: The GRE protocol.  
ESP: The ESP protocol.
- **Source Address**  
A specific host IP address can also be specified, or a range of IP addresses via a bitmask (the box following the /).
- **Destination Address**  
A specific IP address can also be specified, or a range of IP addresses via a bitmask (the box following the /).

Port Mapping Settings	
Port Mapping rule Settings	
Index	<input type="text" value="1"/>
Description	<input type="text"/>
Protocol	<input type="text" value="All"/> ?
Remote Address	<input type="text"/> ?
Remote Port	<input type="text"/> ?
Local Address	<input type="text"/> ?
Local Port	<input type="text"/> ?
<input type="button" value="Save"/> <input type="button" value="Close"/>	

## Firewall->Port Mapping

- **Description**  
Add a description for this rule.
- **Protocol**  
All: Any protocol number.  
TCP: The TCP protocol.  
UDP: The UDP protocol.
- **Remote Address**  
Enter a WAN IP address that is allowed to access the unit.
- **Remote Port**  
Enter the external port number range for incoming requests.

- Local Address**  
Sets the LAN address of a device connected to one of the Fusion's LAN interfaces. Inbound requests will be forwarded to this IP address.
- Local Port**  
Sets the LAN port number range used when forwarding to the destination IP address.

ACL	Port Mapping	DMZ	NAT	URL Filter
General Settings				
Enable <input type="checkbox"/>				
Remote Address <input type="text" value="0.0.0.0/0"/> ?				
DMZ Host Address <input type="text"/>				

Firewall->DMZ

- Enable**  
Check this box to enable DMZ function.
- Remote Address**  
Optionally restricts DMZ access to only the specified WAN IP address.  
**NOTE:** If set to 0.0.0.0/0, the DMZ is open to all incoming WAN IP addresses.
- DMZ Host Address**  
The WAN IP address which has all ports exposed except ports defined in the Port Forwarding configuration.

1-1 NAT Settings	
1-1 NAT Settings	
Index	<input type="text" value="1"/>
Description	<input type="text"/>
Interface Address	<input type="text"/>
Host Address	<input type="text"/>
Interface To Host	<input type="text"/>
<div>SaveClose</div>	

Firewall->NAT

- Description**  
Enter a description of 1-to-1 NAT setting.
- Interface Address**  
Specify the interface address that need to be accessed before NAT.
- Host Address**  
Specify the host address that need to be accessed after NAT.
- Interface To Address**



Specify the interface that connected to host, like lan0, lan1, lan2, lan3.

URL Filter Settings

URL Filter Settings

Index

1

URL

Save

Close

Firewall->URL Filter

- URL**  
Enter the URL to block the data traffic to go to the website. For example, www.google.com

4.5.2 Route

Static Routing refers to a manual method of setting up routing between networks. Select the Static Routing tab to add static routes to the Static Route Table.

Please refer current route table as below.

Status	Static Route				
Route Table Information					
Index	Destination	Netmask	Gateway	Metric	Interface
1	192.168.5.0	255.255.255.0	0.0.0.0	0	lan0

Route->Route Table Information

- Destination**  
Displays the destination of routing traffic.
- Netmask**  
Displays the subnet mask of this routing.
- Gateway**  
Displays the gateway of this interface. This is used for routing packets to remote networks.
- Metric**  
Displays the metric value of this interface.
- Interface**  
Displays the outbound interface of this route.

Static Route Settings

Static Route Settings

Index	<input type="text" value="1"/>
Description	<input type="text"/>
IP Address	<input type="text"/>
Netmask	<input type="text"/>
Gateway	<input type="text"/>
Metric	<input type="text" value="0"/> ?
Interface	<input type="text" value="lan0"/> ▼

Save

Close

Route->Static Route Settings

- Description**  
Enter the description of current static route rule.
- IP Address**  
Enter the IP address of the destination network.
- Netmask**  
Enter the subnet mask of the destination network.
- Gateway**  
Enter the IP address of the local gateway.
- Metric**  
Enter the metric value of current static route rule. The smaller value, the higher priority.
- Interface**  
Select the interface of the destination network.

## 4.5.3 VRRP

The Virtual Router Redundancy Protocol (VRRP) is a computer networking protocol that provides automatic assignment of available Internet Protocol (IP) routers for participating hosts. The VRRP router who has the highest number will become the virtual master router. The VRRP router number ranges from 1 to 255 and usually we use 255 for the highest priority and 100 for backup. If the current virtual master router receives an announcement from a group member (Router ID) with a higher priority, then the latter will pre-empt and become the virtual master router.

VRRP	
VRRP Network Settings	
Index	1
Enable	<input checked="" type="checkbox"/>
Enable No Preempt	<input type="checkbox"/>
Interface	LAN0
Virtual Router ID	1
Authentication Type	None
Priority	100
Interval	1
Virtual IP Address	
<div>Save Close</div>	

### Network->VRRP

- **Enable**  
Check this box will enable VRRP.
- **Enable No Preempt**  
Check this box to Prohibit the preemption of the primary router. When no-preempt is configured, the backup router cannot preempt the primary router even if the backup router has a higher priority.
- **Interface**  
Select the interface of Virtual Router.
- **Virtual Router ID**  
User-defined Virtual Router ID. Range: 1-255.
- **Authentication Type**  
Select the authentication type for VRRP.
- **Priority**  
Enter the VRRP priority range is 1-254 (a bigger number indicates a higher priority).
- **Interval**  
Heartbeat package transmission time interval between routers in the virtual IP group. Range: 1-255.
- **Virtual IP Address**  
Enter the virtual IP address of virtual gateway.

## 4.5.4 IP Passthrough

IP Passthrough mode disables NAT and routing and passes the WAN IP address from the WAN interface to the device connected on the local Interface. It is used instead of Network Address Translation (NAT) in order to make the router "transparent" in the communication process.

The screenshot shows the 'IP Passthrough' configuration page with a 'General Settings' tab selected. The 'Enable' checkbox is checked. The 'Passthrough Host MAC' field is empty with a help icon. The 'Remote HTTPS Access Reserved' checkbox is checked, while 'Remote Telnet Access Reserved' and 'Remote SSH Access Reserved' are unchecked.

IP Passthrough	
General Settings	
Enable	<input checked="" type="checkbox"/>
Passthrough Host MAC	<input type="text"/> ⓘ
Remote HTTPS Access Reserved	<input checked="" type="checkbox"/>
Remote Telnet Access Reserved	<input type="checkbox"/>
Remote SSH Access Reserved	<input type="checkbox"/>

### Network->IP Passthrough

- **Enable**  
Check this box will enable IP Passthrough.
- **Passthrough Host MAC**  
Enter the MAC of passthrough host to receive the WAN IP address.
- **Remote HTTPS Access Reserved**  
Check this box to allow to remote access the router via https while enable IP Passthrough mode.
- **Remote Telnet Access Reserved**  
Check this box to allow to remote telnet to the router while enable IP Passthrough mode.
- **Remote SSH Access Reserved**  
Check this box to allow to remote SSH to the router while enable IP Passthrough mode.

## 4.6 Applications

### 4.6.1 DDNS

DDNS is a system that allows the domain name data of a computer with a varying (dynamic) IP addresses held in a name server to be updated in real time in order to make it possible to establish connections to that machine without the need to track the actual IP addresses at all times. A number of providers offer Dynamic DNS services (DDNS), free or for a charge.

You could review the status of DDNS as below.

Status

DDNS

DDNS Status

Index	Status	Hostname	Public IP Address
-------	--------	----------	-------------------

Status

DDNS

General Settings

Check IP Interval

300

?

Log Level

Error

DDNS Settings

Index	Enable	Provider	Hostname	Username
-------	--------	----------	----------	----------

DDNS Settings

DDNS Settings

Index

1

Enable

☒

Provider

no-ip

Hostname

Enable SSL

☒

Username

Password

Save

Close

#### DDNS

- Status**  
Display the DDNS status.
- Hostname**  
Display the hostname of DDNS.
- Public IP Address**  
Display the public IP address.
- Check IP Interval**  
Enter the interval, the modem will update the Dynamic DNS server of its carrier assigned IP address.
- Log Level**

Select the log output level from “none”, “Error”, “Notice”, “Info” and “Debug”.

- **Enable**  
Check this box to enable the DDNS service.
- **Provider**  
Select the DDNS provider from the list, options from “DynDNS”, “no-ip”, “3322” and custom.
- **Hostname**  
Enter the hostname associated with the account.
- **DDNS Server**  
The internet address to communicate the Dynamic DNS information to. This option is available after you select **custom** on DDNS Provider.
- **DDNS Path**  
DDNS path for custom type.
- **Check IP Server**  
Check IP Server for custom type
- **Check IP Path**  
Check IP Path for custom type.
- **Enable SSL**  
Enable SSL for connection.
- **Username**  
Enter the username used when setting up the account. Used to login to the Dynamic DNS service.
- **Password**  
Enter the password associated with the account.

# 4.6.2 SMS

SMS allows user to send the SMS to control the router or get the running status of the router.

SMSGatewayNotification

General Settings

Enable

Enable SMS Control

Authentication Type

Password

Allow Phone Book

Index

Description

Phone Number

Phone Number Settings

Allow Phone Book

Index

1

Description

Phone Number

Save

Close

Application->SMS

- Enable**  
Check this box to enable SMS feature.
- Enable SMS Control**  
Check this box to enable SMS control feature.
- Authentication Type**  
Specify the authentication mode for SMS, optional for "None" and "Password".
- Description**  
Enter the description of the Phone Book
- Phone Number**  
Enter the special phone number and only allow this phone number to send SMS to the router

SMS Gateway allow to send SMS messages by using a valid syntax from admin device.

SMS	Gateway	Notification
<b>General Settings</b>		
Enable	<input checked="" type="checkbox"/>	
Authentication Type	Password	
SMS Source	Serial Port	
<b>Serial Port Settings</b>		
Serial Port	COM1	
Baud Rate	115200	
Data Bits	8	
Stop Bits	1	
Parity	None	
Application->SMS>Gateway		

- **Enable**  
Check the box will enable SMS gateway.
- **Authentication Type**  
Specify the authentication mode for SMS, optional for "None" and "Password".
- **SMS Source**  
Specify SMS source to receive valid syntax, optional for "Serial Port" and "HTTP(S) GET/POST".
- **SMS Message Format**  
Specify the SMS format between "Text" and "PDU" when reading SMS or reading SMS list via "HTTP(S) GET/POST"
- **Serial Port**  
Select the serial port from COM1 or COM2.
- **Baud Rate**  
Select the serial port baud rate. Supported values are 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400, 460800 or 921600.
- **Data Bits**  
Select the values from 8.
- **Stop Bits**  
Select the values from 1 or 2.
- **Parity**  
Select values from none, even, odd.

SMS	Gateway	Notification
<b>General Settings</b>		
Enable	<input type="checkbox"/>	
Authentication Type	Password	
SMS Source	HTTP(S) GET/POST	
SMS Message Format	Text	



## Application->SMS>Gateway

- **Enable**  
Check the box will enable SMS gateway.
- **Authentication Type**  
Specify the authentication mode for SMS, optional for "None" and "Password".
- **SMS Source**  
Specify SMS source to receive valid syntax, optional for "HTTP(S) GET/POST".
- **SMS Message Format**  
Specify SMS message format, optional for "Text" and "PDU", effective only when reading SMS(/sms/read/) or reading SMS list(/sms/list/).

SMS Notification feature allow to send SMS notification to the pre-setting phone number when some of router status changed.

Notification Settings	
Index	1
Enable	<input checked="" type="checkbox"/>
Description	
Phone Number	
Enable Timestamp	<input checked="" type="checkbox"/>
Startup	<input type="checkbox"/>
Reboot	<input type="checkbox"/>
NTP Update	<input type="checkbox"/>
Ethernet Port	<input type="checkbox"/>
WWAN Port	<input type="checkbox"/>
Active Link	<input type="checkbox"/>
Digital Input	<input type="checkbox"/>
Digital Output	<input type="checkbox"/>
IPSec Connection	<input type="checkbox"/>
Openvpn Connection	<input type="checkbox"/>
Modbus Alarm	<input type="checkbox"/>

## Application->SMS>Notification

- **Index**  
Display the index of the notification channel, maximum is 10.
- **Description**  
Add the description for notification channel.
- **Phone Number**  
Pre-setting phone number to receive the notification.
- **Timestamp**  
Check this box to enable timestamp on the SMS notify.

- **Startup**  
Send SMS notification to the pre-setting phone number when system startup.
- **Reboot**  
Send SMS notification to the pre-setting phone number when system reboot.
- **NTP Update**  
Send SMS notification to the pre-setting phone number when NTP update successfully.
- **LAN Port**  
Send SMS notification to the pre-setting phone number when LAN port status changed.
- **WAN Port**  
Send SMS notification to the pre-setting phone number when WAN port status changed.
- **WWAN Port**  
Send SMS notification to the pre-setting phone number when WWAN port status changed.
- **Active Link**  
Send SMS notification to the pre-setting phone number when active link status changed.
- **IPSec Connection**  
Send SMS notification to the pre-setting phone number when IPSec connection status changed.
- **OpenVPN Connection**  
Send SMS notification to the pre-setting phone number when OpenVPN Connection Status changed.
- **Modbus Alarm**  
Send SMS notification to the pre-setting phone number when Modbus Alarm Contrast Rule List is triggered.

### 4.6.3 Schedule Reboot

Schedule reboot allows user to define the time for router reboot itself.

Schedule Reboot	
General Settings	
Enable	<input checked="" type="checkbox"/>
Time to Reboot	<input type="text" value="00:00"/> ?
Day to Reboot	<input type="text" value="0"/> ?

#### Application->Schedule Reboot

- **Enable**  
Check this box to enable schedule reboot feature.
- **Time to Reboot**  
Enter the time of each day to reboot device. Format: HH (00-23):MM (00-59).
- **Day to Reboot**  
Enter the day of each month to reboot device. 0 means every day.

## 4.6.4 GPS

GPS (Global Positioning System) is a high-precision radio navigation positioning system based on satellites. It can provide the accurate positioning, speed measurement and high precision standard time.

Status	GPS			
GPS Status				
	Status			
	Satellites Visible			
	Satellites Used			
	Latitude			
	Longitude			
	Altitude			
	Horizontal speed			
Channel Status				
Index	Status	Remote Address	Remote Port	Status

### Application->GPS->Status

- **Status**  
Displays current GPS status.
- **Satellites Visible**  
Displays the number of the visible satellites.
- **Satellites Used**  
Displays the number of the visible satellites in using.
- **Latitude**  
Displays the latitude of GPS.
- **Longitude**  
Display the longitude of GPS.
- **Altitude**  
Display the altitude of GPS.
- **Horizontal speed**  
Display the horizontal speed of GPS.
- **Status (Channel)**  
Display the transmission protocol of the channel.
- **Remote Address**  
Display the remote IP address of the channel.
- **Remote Port**  
Display the remote port of the channel.
- **Status (Channel)**  
Display the status of the channel.

**Status**      **GPS**

**General Settings**

Enable ☒

Enable A-GPS ☒ ?

**Report Channel Settings**

Index	Description	Protocol
<b>Channel Settings</b>		
<b>Report Channel Settings</b>		
Index	1	
Description		
Report GSV	<input checked="" type="checkbox"/>	
Report GGA	<input checked="" type="checkbox"/>	
Report VTG	<input checked="" type="checkbox"/>	
Report RMC	<input checked="" type="checkbox"/>	
Report GSA	<input checked="" type="checkbox"/>	
Report Interval	5	?
NMEA Prefix		?
Protocol	TCP Client	
Remote Address		
Remote Port	2000	

Save Close Save Apply

## Application->GPS->GPS

- **Enable**  
Check this box to enable GPS.
- **Enable A-GPS**  
Check this box to enable A-GPS (Assisted Global Positioning).
- **Description**  
Specify the description of the GPS transmission channel.
- **Report GSV**  
Check this box to enable to send the GPS data with GSV format.
- **Report GGA**  
Check this box to enable to send the GPS data with GGA format.
- **Report VTG**  
Check this box to enable to send the GPS data with VTG format.
- **Report RMC**  
Check this box to enable to send the GPS data with RMC format.
- **Report GSA**  
Check this box to enable to send the GPS data with GSA format.
- **Report Interval**  
Specify the interval time to send the GPS data to remote server.
- **NMEA Prefix**  
Self-defined the GPS data prefix to send to remote server.

- **Protocol**  
Specify the transmission protocol of the channel.
- **Remote Address**  
Specify the remote IP address to receive the GPS data.
- **Remote Port**  
Specify the remote port to receive the GPS data.

### 4.6.5 Call

Call reboot allow the user to make a call to the router to control it restart.

Call

General Settings

Enable Call Control

☐

Call Reboot

☒

Allow Phone Book

Index	Description	Phone Number
-------	-------------	--------------

Phone Number Settings

Allow Phone Book

Index

1

Description

Phone Number

Save

Close

#### Application->Call

- **Enable Call Control**  
Check this box to enable call control feature.
- **Call Reboot**  
Check this box to enable call reboot feature.
- **Description**  
Define the description of the phone book
- **Phone Number**  
Specify the phone number that allow to make a call to the router.

## 4.7 VPN

### 4.7.1 OpenVPN

OpenVPN is an open source virtual private network (VPN) product that offers a simplified security framework, modular network design, and cross-platform portability.

You could review all OpenVPN connection as below.

Status    OpenVPN    X.509 Certificate    Configuration Files						
OpenVPN Information						
Index	Enable	Description	Mode	Status	Uptime	Local Virtual IP
OpenVPN Server Status						
Index	Common Name	Status	Uptime	Remote Virtual IP	Remote IP	Remote Port

#### VPN->OpenVPN->Status>OpenVPN Information

- **Enable**  
Displays current OpenVPN settings is enable or disable.
- **Mode**  
Displays current working mode of OpenVPN.
- **Status**  
Displays the current VPN connection status.
- **Uptime**  
Displays the connection time since VPN is established.
- **Local Virtual IP**  
Displays the virtual IP address obtain from remote side.

#### VPN->OpenVPN->Status>OpenVPN Server Status

- **Common Name**  
Displays the common name of OpenVPN client.
- **Status**  
Displays the current VPN connection status.
- **Uptime**  
Displays the connection time since VPN is established.
- **Remote Virtual IP**  
Displays the virtual IP address of OpenVPN client.
- **Remote IP**  
Displays the remote IP address of OpenVPN client.
- **Remote Port**  
Displays the remote port obtain of OpenVPN client.

OpenVPN Settings	
General Settings	
Index	1
Enable	<input checked="" type="checkbox"/>
Description	
Mode	Client
Protocol	UDP
Connection Type	TUN
Server Address	
Server Port	1194
Authentication Method	X.509
Encryption Type	BF-CBC
Renegotiate Interval	3600
Keepalive Interval	20
Keepalive Timeout	60
Fragment	0
Private Key Password	
Output Verbosity Level	3

### VPN->OpenVPN









- Enable**  
 Check this box to enable OpenVPN tunnel.
- Description**  
 Enter a description for this OpenVPN tunnel.
- Mode**  
 Select from "P2P", "Client" or "Server".
- Protocol**  
 Select from "UDP", "TCP Client" or "TCP Server"
- Connection Type**  
 Select from "TUN", "TAP" which are two different kinds of device interface for OpenVPN. The difference between TUN and TAP device is that a TUN device is a point-to-point virtual device on network while a TAP device is a virtual device on Ethernet.
- Server Address**  
 Enter the IP address or domain of remote server.
- Server Port**  
 Enter the negotiate port on OpenVPN server.

- **Max Client**  
Allow max OpenVPN client connect to OpenVPN server.
- **Authentication Method**  
Select from "X.509", "Pre-shared", "Password", and "X.509 And Password".
- **Encryption Type**  
Select from "BF-CBC", "DES-CBC", "DES-EDE-CBC", "DES-EDE3-CBC", "AES-128-CBC", "AES-192-CBC" and "AES-256-CBC".
- **Username**  
Enter the username for authentication when selection from "Password" or "X.509 And Password".
- **Password**  
Enter the password for authentication when selection from "Password" or "X.509 And Password".
- **Local IP Address**  
Enter the local virtual IP address when select "P2P" and "OpenVPN Server" mode.
- **Remote IP Address**  
Enter the remote virtual IP address when select "P2P" mode.
- **Local Port**  
Specify the OpenVPN Server port, default is 1194.
- **Topology**  
Select the possible topology from "Subnet" and "Net30"  
Subnet: The recommended topology for modern servers. Note that this is not the current default. Addressing is done by IP & netmask.  
Net30: This is the old topology for support with Windows clients running 2.0.9 or older clients. This is the default as of OpenVPN 2.3, but not recommended for current use. Each client is allocated a virtual /30, taking 4 IPs per client, plus 4 for the server.
- **Subnet**  
Specify the subnet for the OpenVPN client. Default is 10.8.0.0
- **Subnet Netmask**  
Specify the subnet netmasks for OpenVPN client. Default is 255.255.255.0
- **TAP Bridge**  
Select the specified LAN that bridge with OpenVPN tunnel when select "TAP" connection type.
- **Renegotiate Interval**  
Enter the renegotiate interval if connection is failed.
- **Keepalive Interval**  
Enter the keepalive interval to check the tunnel is active or not.
- **Keepalive Timeout**  
Enter the keepalive timeout, once connection is failed it will trigger the OpenVPN reconnect.
- **Fragment**  
Enter the fragment size, 0 means disable.
- **Private Key Password**  
Enter the private key password for authentication when selection from "X.509" or "X.509 And Password".
- **Output Verbosity Level**  
Enter the level of the output log and values.



### VPN->OpenVPN->Advanced Settings

- **Enable NAT**  
Check this box to enable NAT, the source IP of host behind router will be disguised before accessing the remote end.
- **Enable Default Gateway**  
Check this box to enable default gateway, all the data traffic will go through the VPN tunnel.
- **Enable PKCS#12**  
It is an exchange of digital certificate encryption standard, used to describe personal identity information.
- **Enable CRL**  
Check this box to enable CRL(Certificate Revocation List).
- **Enable Client to Client**  
Check this box to allow client to communicate with each other.
- **Enable Duplicate CN**  
Check this box allow multiple clients connect to the server with the same certificate/key files or common names.
- **Enable IP Persist**  
Check this box to keep the IP address unchanged.
- **Enable X.509 Attribute nsCertType**  
Require that peer certificate was signed with an explicit nsCertType designation of "server".
- **Enable HMAC Firewall**  
Add additional layer of HMAC authentication on the top of the TLS control channel to protect against DoS attacks.
- **Enable Compression LZ0**  
Compress the data.
- **Additional Configurations**  
Enter some other options of OpenVPN in this field. Each expression can be separated by a ','.

Status	OpenVPN	<u>X.509 Certificate</u>	Configuration Files
<b>X.509 Certificate Import</b>			
OpenVPN Mode	Client ▼		
Connection Index	1 ▼		
CA Certificate	Choose File	No file chosen	
Local Certificate File	Choose File	No file chosen	
Local Private Key	Choose File	No file chosen	
HMAC Firewall Key	Choose File	No file chosen	
Pre-shared Key	Choose File	No file chosen	
PKCS#12 Certificate	Choose File	No file chosen	
User-Password File	Choose File	No file chosen	
Private Key Password File	Choose File	No file chosen	
<b>X.509 Certificate Files</b>			
Index	File Name	File Size	Date Modified

### VPN->OpenVPN->X.509 Certificate

- **OpenVPN Mode**  
Select OpenVPN working mode between Server and Client.
- **Connection Index**  
Displays the current connection index for OpenVPN channel.
- **CA Certificate**  
Import CA certificate file.
- **Local Certificate File**  
Import Local Certificate file.
- **Local Private Key**  
Import Local Private Key file.
- **DH File**  
Import DH file when works as OpenVPN server.
- **HMAC Firewall Key**  
Import HMAC Firewall Key file.
- **Pre-shared Key**  
Import the pre-shared key file.
- **PKCS#12 Certificate**  
Import PKCS#12 Certificate.
- **User-Password File**  
Import the username and password file when import the OpenVPN client file.
- **Private Key Password File**  
Import the private key password file when import the OpenVPN client file.
- **CRL File**  
Import CRL file.

StatusOpenVPNX.509 CertificateConfiguration Files

Configuration Files Settings

Connection Index

1

Configuration Files

Choose FileNo file chosen

Configuration Files Download

Download

Configuration Files List

Index

File Name

File Size

Date Modified

VPN->OpenVPN->Configuration Files

- Connection Index**  
Select OpenVPN connection index.
- Configuration Files**  
Import the OpenVPN client file.
- Configuration Files Download**  
Download the OpenVPN client configuration.
- Configuration Files List**  
Display the imported OpenVPN client file.

## 4.7.2 IPSec

IPSec facilitates configuration of secured communication tunnels. The various tunnel configurations will be displayed in the Tunnel Table at the bottom of the page. All tunnels are create using the ESP (Encapsulating Security Payload) protocol.

Status IPSec				
IPSec Information				
Index	Enable	Description	Status	Uptime

### VPN->IPSec->Status

- **Enable**  
Displays current IPSec settings is enable or disable.
- **Description**  
Displays the description of current VPN channel.
- **Status**  
Displays the current VPN connection status.
- **Uptime**  
Displays the connection time since VPN is established.

IPSec Settings	
General Settings	
Index	1
Enable	<input checked="" type="checkbox"/>
Description	
Remote Gateway	
IKE Version	IKEv1
Connection Type	Tunnel
Negotiation Mode	Main
Authentication Method	Pre-shared Key
Local Subnet	
Local Pre-shared Key	
Local ID Type	IPv4 Address
Local ID	
Remote Subnet	
Remote ID Type	IPv4 Address
Remote ID	

## VPN->IPSec

- **Enable**  
Select Enable will launch the IPSec process.
- **Description**  
Enter a description for this IPSec VPN tunnel.
- **Remote Gateway**  
Enter the IP address of the remote endpoint of the tunnel.
- **IKE Version**  
Internet Key Exchange, select from "IKEv1" or "IKEv2".
- **Connection Type**  
Select from "Tunnel" or "Transport".  
Tunnel: In tunnel mode, the entire IP packet is encrypted and authenticated. It is then encapsulated into a new IP packet with a new IP header. Tunnel mode is used to create virtual private networks for network-to-network communications.  
Transport: In transport mode, only the payload of the IP packet is usually encrypted or authenticated. The routing is intact, since the IP header is neither modified nor encrypted.
- **Negotiation Mode**  
Select from "Main" or "Aggressive".
- **Authentication Method**  
Select from "Pre-shared Key" or "Pre-shared Key and Xauth".
- **Local Subnet**  
Enter the IP address with mask if a network beyond the local LAN will be sending packets through the tunnel. Multiple subnets separated by commas.  
NOTE: The Remote subnet and Local subnet addresses must not overlap!
- **Local Pre-shared Key**  
Enter the pre-shared key which match the remote endpoint.
- **Local ID Type**  
Select from "IPv4 Address", "FQDN", "User-FQDN" for authentication with the remote endpoint.
- **Local ID**  
The content of Local ID need to match "Local ID type".
- **Xauth Identity**  
Enter Xauth identity after "Pre-shared Key and Xauth" on authentication Method is enabled.
- **Xauth Password**  
Enter Xauth password "Pre-shared Key and Xauth" on authentication Method is enabled.
- **Remote Subnet**  
Enter an IP address with mask if encrypted packets are also destined for the specified network that is beyond the Remote IP Address. Multiple subnets separated by commas.  
NOTE: The Remote subnet and Local subnet addresses must not overlap!
- **Remote ID Type**  
Select from "IPv4 Address", "FQDN", "User-FQDN" for authentication with the remote endpoint.
- **Remote ID**  
The content of Remote ID need to match "Remote ID type".

IKE Proposal Settings	
Encryption Algorithm	AES-256
Hash Algorithm	SHA2 256
Diffie-Hellman Group	Group5(modp1536)
Lifetime	1440
ESP Proposal Settings	
Encryption Algorithm	AES-256
Hash Algorithm	SHA2 256
Diffie-Hellman Group	Group5(modp1536)
Lifetime	60
Advanced Settings	
DPD Interval	30
DPD Timeout	90
Additional Configurations	
<div>Save</div> <div>Close</div>	

## VPN->IPSec

- **Encryption Algorithm (IKE)**  
Select 3DES AES-128, AES-192, or AES-256 encryption.
- **Hash Algorithm (IKE)**  
Select from MD5, SHA1, SHA2 256, SHA2 384 or SHA2 512 hashing.
- **Diffie-Hellman Group (IKE)**  
Negotiate (None) or use 768 (Group 1), 1024 (Group 2), 1536 (Group 5) or 2048 (Group 14) etc.
- **Lifetime (IKE)**  
How long the keying channel of a connection should last before being renegotiated.
- **Encryption Algorithm (ESP)**  
Select 3DES AES-128, AES-192, or AES-256 encryption.
- **Hash Algorithm (ESP)**  
Select from MD5, SHA1, SHA2 256, SHA2 384 or SHA2 512 hashing.
- **Diffie-Hellman Group (ESP)**  
Negotiate (None) or use 768 (Group 1), 1024 (Group 2), 1536 (Group 5) or 2048 (Group 14) etc.
- **Lifetime (ESP)**  
How long a particular instance of a connection should last, from successful negotiation to expiry.
- **DPD Interval**  
Enter the interval after which DPD is triggered if no IPsec protected packets is received from the peer.
- **DPD Timeout**  
Enter the remote peer probe response timer.
- **Additional Configurations**  
Enter some other options of IPsec in this field. Each expression can be separated by a ';'.

### 4.7.3 GRE

Generic Routing Encapsulation (GRE) is a protocol that encapsulates packets in order to route other protocols over IP networks. It's a tunneling technology that provides a channel through which encapsulated data message could be transmitted and encapsulation and decapsulation could be realized at both ends.

<u>Status</u>		GRE		
GRE Information				
Index	Enable	Description	Mode	Status

VPN->GRE->Status

- Enable**  
Displays current GRE settings is enable or disable.
- Description**  
Displays the description of current VPN channel.
- Mode**  
Displays the current VPN mode.
- Status**  
Displays the current VPN connection status.

**GRE Settings**

**General Settings**

Index

1

Enable

☒

Description

Mode

Layer 3 ▼

Remote Gateway

Local Virtual IP

Local Virtual Netmask

255.255.255.252

Tunnel key

?

Enable NAT

☐

Enable Default Route

☐

**Advanced Settings**

Binding Interface

?

Save

Close

## VPN->GRE

- **Enable**  
Check this box to enable GRE.
- **Description**  
Enter the description of current VPN channel.
- **Mode**  
Specify the running mode of GRE, optional are "Layer 2" and "Layer 3".
- **Remote Gateway**  
Enter the remote IP address of peer GRE tunnel.
- **Local Virtual IP**  
Enter the local tunnel IP address of GRE tunnel.
- **Local Virtual Netmask**  
Enter the local virtual netmask of GRE tunnel.
- **Tunnel Key**  
Enter the authentication key of GRE tunnel.
- **Enable NAT**  
Check this box to enable NAT function.
- **Bridge Interface**  
Specify the bridge interface work with Layer 2 mode.
- **Enable Default Route**  
Check this box to make all the traffic go through VPN tunnel.
- **Binding Interface**  
Only specified interface turn into active WAN will start the VPN tunnel.




## 4.8 Maintenance

### 4.8.1 Upgrade

When newer versions of NR500 firmware become available, the user can manually update the unit by uploading a package to the unit.

**NOTE:** The unit need manually reboots once the upload completes, thus taking the NR500 router out of service during approximately 1 minute. Unless otherwise stated, the user is not expected to take any special precautions.


**CAUTION:** It is important to have a stable power source and ensure that power to the Fusion is not interrupted during a firmware upgrade.



### 4.8.2 Software

When release a new feature (APP Package) of NR500 router, the user can manually install to the unit by uploading a package. Or user can uninstall this feature (APP Package) from router.

**NOTE:** The unit need manually reboots once the upload/uninstall completes, thus taking the NR500 router out of service during approximately 1 minute. Unless otherwise stated, the user is not expected to take any special precautions.



Click to upload the APP Package.



Click to delete the APP Package.

*Note: We are working different kinds of the APP Packages. Please contact us to get them in case of you would like to test.*

## 4.8.3 System

This section allows you to review the device system settings.

General	Accounts	Syslog	Web Server	Telnet	SSH	Security
<b>General Settings</b>						
Hostname		<input type="text" value="navigateworx.router"/>				
User LED Type		<input type="text" value="None"/>				
<b>Time Zone Settings</b>						
Time Zone		<input type="text" value="UTC+08:00"/>				
Customized Time Zone		<input type="text"/> ?				
<b>Time Synchronisation</b>						
Enable		<input checked="" type="checkbox"/>				
Primary NTP Server		<input type="text" value="pool.ntp.org"/>				
Secondary NTP Server		<input type="text" value="1.pool.ntp.org"/>				
Synchronize Modem Time		<input type="checkbox"/>				
Enable NTP Server		<input type="checkbox"/>				

### System->General

- **Hostname**  
User-defined router name, which might be use for IPSec local ID identify.
- **User LED Type**  
Defined the User LED behavior.
- **Time Zone**  
Select the zone where the device is in use.
- **Customized Time Zone**  
Customized the zone where the device is in use.
- **Enable (NTP Client)**  
Selected Enabled to utilize the NTP client to synchronize the device clock over the network using a time server (NTP server).
- **Primary NTP Server**  
Enter the IP address (or host name) of the primary time server.
- **Secondary NTP Server**  
Enter the IP address (or host name) of the secondary time server.
- **Synchronize Modem Time**  
Synchronize the time from cellular module.
- **Enable NTP Server**  
Check the box to make the router as a NTP server.

GeneralAccountsSyslogWeb ServerTelnetSSHSecurity

Account Settings

Administrator

admin

Old Password

New Password

Confirm Password

Visitor Settings

Index

Username

Password

System->Account

- Administrator**  
Displays the name of current administrator, default as "admin".
- Old Password**  
Enter the old password of administrator.
- New Password**  
Enter the new password of administrator.
- Confirm Password**  
Confirm the new password of administrator.

Account Settings

Account Settings

Index

1

Username

Password

Save

Close

System->Account



- Username**  
Enter a username of visitor privilege
- Password**  
Enter the new password of current visitor account.

Syslog displays system logs that are stored in the log buffers.

General	Accounts	Syslog	Web Server	Telnet	SSH	Security
<b>General Settings</b>						
		Log Location	RAM ▼			
		Log Level	Debug ▼			
<b>Remote Syslog Settings</b>						
		Enable Remote Syslog	<input type="checkbox"/>			
		Remote Syslog Server	<input type="text"/>			
		Remote Syslog Port	514			

## System->Syslog

- **Log Location**  
Select the log store location from "RAM" or "Flash".
- **Log Level**  
Select the log output level from "Debug", "Notice", "Info", "Warning" or "Error".
- **Enable Remote Syslog**  
Check this box to enable remote syslog connection.
- **Remote Syslog Server**  
Enter the IP address of remote syslog server.
- **Remote Syslog Port**  
Enter the port for remote syslog server listening.

General	Accounts	Syslog	Web Server	Telnet	SSH	Security
<b>General Settings</b>						
		HTTP Port	80			
		HTTPS Port	443			
<b>Certificate Settings</b>						
		Private Key	Choose File	No file chosen		
		Certificate File	Choose File	No file chosen		

## System->Web Server

- **HTTP Port**  
Enter the port for Hypertext Transfer Protocol. A well-known port for HTTP is port 80.
- **HTTPS Port**  
Enter the port for HTTPS Protocol. A well-known port for HTTPS is port 443.
- **Private Key**  
Import private Key file for HTTPS connection.
- **Certificate File**  
Import certificate file for HTTPS connection.

General	Accounts	Syslog	Web Server	<u>Telnet</u>	SSH	Security
General Settings						
Telnet Port			<input type="text" value="23"/>			

### System->Telnet

- **Telnet Port**  
Enter the port for telnet access. A well-known port for HTTP is port 23.

General	Accounts	Syslog	Web Server	<u>Telnet</u>	<u>SSH</u>	Security
General Settings						
SSH Port			<input type="text" value="22"/>			
Allow Password Authentication			<input checked="" type="checkbox"/>			
Public Key			<input type="text"/>			

### System->SSH

- **SSH Port**  
Enter the port for SSH access. A well-known port for HTTP is port 22.
- **Allow Password Authentication**  
Check this box to enable SSH authentication.
- **Public Key**  
Enter the public Key SSH authentication.

General	Accounts	Syslog	Web Server	Telnet	SSH	<u>Security</u>
<b>Access Settings</b>						
Remote HTTP Access						<input type="checkbox"/>
Remote HTTPS Access						<input checked="" type="checkbox"/>
Remote Telnet Access						<input type="checkbox"/>
Remote SSH Access						<input checked="" type="checkbox"/>
Local HTTP Access						<input checked="" type="checkbox"/>
Local HTTPS Access						<input checked="" type="checkbox"/>
Local Telnet Access						<input checked="" type="checkbox"/>
Local SSH Access						<input checked="" type="checkbox"/>
<b>Ping Settings</b>						
Remote Ping Request						<input checked="" type="checkbox"/>
Local Ping Request						<input checked="" type="checkbox"/>
DDoS Defense						<input checked="" type="checkbox"/>

## System->Security

- **Remote HTTP Access**  
Check this box to allow remote HTTP access.
- **Remote HTTPS Access**  
Check this box to allow remote HTTPS access.
- **Remote Telnet Access**  
Check this box to allow remote Telnet access.
- **Remote SSH Access**  
Check this box to allow remote SSH access.
- **Local HTTP Access**  
Check this box to allow local HTTP access.
- **Local HTTPS Access**  
Check this box to allow local HTTPS access.
- **Local Telnet Access**  
Check this box to allow local Telnet access.
- **Local SSH Access**  
Check this box to allow local SSH access.
- **Remote Ping Request**  
Check this box to allow remote ping request.
- **Local Ping Request**  
Check this box to allow local ping request.
- **DDoS Defense**  
Check this box to enable DDoS defense.

## 4.8.4 Configuration

The Unit Configuration tab allows you to save parameters (settings in the Web interface) to a file. Conversely, if you have saved settings from the NR500 router to a file, you can Import these previously-saved configuration settings to the NR500 router as well.

The screenshot shows the 'Configuration' tab with a 'Configuration Management' section. It includes buttons for 'Restore' (Factory Settings), 'Download' (Configuration File Download), and 'Backup' (Configuration File Backup). There is a 'Configuration Import Mode' dropdown set to 'All' with a help icon. Below it is a 'Configuration File Upload' section with a 'Choose File' button, 'No file chosen' text, and an upload icon. At the bottom is a 'Configuration File Backup List' table with columns for Index, File Name, and File Size.

Index	File Name	File Size

### System->Configuration

- **Restore**  
Reset the unit to factory default settings.
- **Download**  
Download the configuration file from NR500 router.
- **Backup**  
Backup the currently configuration to "Configuration File Backup list".
- **Configuration Import Mode**  
Select the Mode from "ALL" / "Port".  
ALL: Import the whole Configuration File on "Configuration File Upload".  
Port: Import the port Configuration File on "Configuration File Upload"..
- **File Name**  
Display the file name of the Configuration File.
- **File Size**  
Display the size of the Configuration File.

## 4.8.5 Debug Tools

<u>Ping</u>	Traceroute	AT Debug	Sniffer
<b>Ping Settings</b>			
		Host Address	<input type="text"/>
		Ping Count	<input type="text" value="5"/>
		Local IP Address	<input type="text"/>

### Debug Tools->Ping

- **Host Address**  
Enter a host IP address or domain name for ping.
- **Ping Count**  
Enter the ping times.
- **Local IP Address**  
Enter the ping source IP address or leave it blank.

Ping	<u>Traceroute</u>	AT Debug	Sniffer
<b>Traceroute Settings</b>			
		Host Address	<input type="text"/>
		Max Hops	<input type="text" value="30"/>

### Debug Tools->Traceroute

- **Host Address**  
Enter a host IP address or domain name for traceroute.
- **Max Hops**  
Enter the max hops for traceroute.

Ping	Traceroute	<u>AT Debug</u>	Sniffer
<b>AT Debug Settings</b>			
		AT Command	<input type="text"/>

### Debug Tools->AT Debug

- **AT Command**  
Enter the AT command of the module.



PingTracerouteAT DebugSniffer

Sniffer Settings

Source Host

Source Port

Destination Host

Destination Port

Interface

Sniffer Files List

Index

File Name

File Size

Date Modified

Debug Tools->Sniffer

- Source Host**  
Enter the source host IP address.
- Source Port**  
Enter the source port.
- Destination Host**  
Enter the destination host IP address.
- Destination Port**  
Enter the destination port.
- Interface**  
Enter the interface that the data traffic goes through.
- File Name**  
Display the file name of the packages.
- File Size**  
Display the size of the package.
- Date Modified**  
Display the date of the package.

# Appendix A -Glossary

<b>APN:</b>	Access Point Name
<b>GPRS:</b>	General Packet Radio Service
<b>HSPA:</b>	High Speed Packet Access
<b>HSDPA:</b>	High-Speed Downlink Packet Access
<b>HSUPA:</b>	High-Speed Uplink Packet Access
<b>LTE:</b>	3GPP Long Term Evolution
<b>IMEI:</b>	International Mobile Equipment Identity
<b>ICCID:</b>	Integrated Circuit Card Identifier
<b>PIN:</b>	Personal Identification Number
<b>PPP:</b>	Point-to-Point Protocol
<b>RSSI:</b>	Received Signal Strength Indication
<b>SIM:</b>	Subscriber Identity Module
<b>SMS:</b>	Short Message Service
<b>DHCP:</b>	Dynamic Host Configuration Protocol
<b>LAN:</b>	Local Area Network
<b>LED:</b>	Light-Emitting Diode
<b>NTP:</b>	Network Time Protocol
<b>SMA:</b>	SubMiniature version A (connector)
<b>SSID:</b>	Service Set Identifier
<b>TCP/IP:</b>	Transmission Control Protocol / Internet Protocol
<b>UDP:</b>	User Datagram Protocol
<b>VPN:</b>	Virtual Private Network
<b>Wi-Fi or WiFi:</b>	Wireless Fidelity
<b>VDC:</b>	Voltage, Direct Current

# Appendix B -Q&A

## No Signal

### Phenomenon

NR500 Router modem status show no signal.

### Possible Reason

- Antenna installation is wrong.
- Modem failure.

### Solution

- Check the LTE antenna or replace with new one.
- Check the cellular page confirm modem is detected correctly or not.

## Cannot detect SIM card

### Phenomenon

NR500 Router cannot detect SIM card, cellular is not failed to connect to base station.

### Possible Reason

- SIM card damage.
- SIM bad contact.

### Solution

- Replace SIM card.
- Re-install SIM card.

## Poor Signal

### Phenomenon

NR500 Router no signal or poor signal.

### Possible Reason

- Antenna installation is wrong.
- Area signal weak.

### Solution

- Check the antenna and re-connect it.
- Contact Telecom Operator to confirm signal problem.
- Change to high-gain antenna.

## IPSec VPN established, but LAN to LAN cannot communicate

### Phenomenon

IPSec VPN established, but LAN to LAN cannot communicate

### Possible Reason

- Both subnets are not match the interested traffic.
- IPSec second phase (ESP) settings is not match.

### Solution

- Check the both subnet settings.
- Check IPSec second phase (ESP) setting.

## Forget Router Password

### Phenomenon

Forget router login password.

### Possible Reason

User has changed the password.


### Solution

After router power on, press RESET button between 3 to 10 seconds then release, router need manually reboot and reset to factory default settings (Username/Password is admin/admin).

# Appendix C -Digital IO Scenario

## Digital Input

### Typical Application Diagram



#### DI ELECTRICAL CHARACTERISTICS


1. Galvanic isolation;
2. Over-Voltage Protection: 36 VDC
3. Over-Current Protection: 100mA per channel @ 25°C

#### Dry Contact Typical Application

- Switch ON(Short to V-): DI Logic LOW  
Switch OFF(Open): DI Logic HIGH

## Digital Output

### Typical Application Diagram



#### DO ELECTRICAL CHARACTERISTICS

1. Galvanic isolation
2. Over-Voltage Protection: 36 VDC
3. Over-Current Protection: 50mA per channel @ 25°C

#### Wet Contact Typical Application

- DO Logic LOW: Switch ON (Led ON)  
DO Logic HIGH: Switch OFF (Led OFF)

# Appendix D - CLI

Command-line interface (CLI) is a software interface that provide another configurable way to set parameters on our router. We could use Telnet or SSH connect to our router for CLI input.

## NR500 CLI Access

navigateworx.router login: **admin**

Password: **admin**

>

## CLI reference commands

>?

config	Change to the configuration mode
exit	Exit this CLI session
help	Display an overview of the CLI syntax
ping	Ping
reboot	Reboot system
show	Show running configuration or running status
telnet	Telnet Client
traceroute	TraceRoute
upgrade	Upgrade firmware
version	Show firmware version

**e.g.**

> version

1.0.0 (1017.4)

> show wifi

wifi

```
{
  "status":"Ready",
  "mac":"a8:3f:a1:e0:ab:81",
  "ssid":"NR500-WAN",
  "channel":"6",
  "width":"40 MHz",
  "txpower":"20.00 dBm"
}
```

> ping www.baidu.com

PING www.baidu.com (14.215.177.38): 56 data bytes

64 bytes from 14.215.177.38: seq=0 ttl=54 time=10.826 ms

64 bytes from 14.215.177.38: seq=1 ttl=54 time=10.284 ms  
64 bytes from 14.215.177.38: seq=2 ttl=54 time=10.073 ms  
64 bytes from 14.215.177.38: seq=3 ttl=54 time=10.031 ms  
64 bytes from 14.215.177.38: seq=4 ttl=54 time=10.347 ms

--- www.baidu.com ping statistics ---

5 packets transmitted, 5 packets received, 0% packet loss

round-trip min/avg/max = 10.031/10.312/10.826 ms

>

## How to Configure the CLI

### CONTEXT SENSITIVE HELP

[?] - Display context sensitive help. This is either a list of possible command completions with summaries, or the full syntax of the current command. A subsequent repeat of this key, when a command has been resolved, will display a detailed reference.

### AUTO-COMPLETION

The following keys both perform auto-completion for the current command line. If the command prefix is not unique then the bell will ring and a subsequent repeat of the key will display possible completions.

[enter] - Auto-completes, syntax-checks then executes a command. If there is a syntax error then offending part of the command line will be highlighted and explained.

[space] - Auto-completes, or if the command is already resolved inserts a space.

### MOVEMENT KEYS

[CTRL-A] - Move to the start of the line

[CTRL-E] - Move to the end of the line.

[up] - Move to the previous command line held in history.

[down] - Move to the next command line held in history.

[left] - Move the insertion point left one character.

[right] - Move the insertion point right one character.

### DELETION KEYS

[CTRL-C] - Delete and abort the current line

[CTRL-D] - Delete the character to the right on the insertion point.

[CTRL-K] - Delete all the characters to the right of the insertion point.

[CTRL-U] - Delete the whole line.

[backspace] - Delete the character to the left of the insertion point.

### ESCAPE SEQUENCES

!! - Substitute the the last command line.

!N - Substitute the Nth command line (absolute as per 'history' command)

!-N - Substitute the command line entered N lines before (relative)