

NR500 Series Industrial Cellular VPN Router

Application Note 015

IPSec_FQDN_Pre shared key and Xauth with CISCO router

Version: V1.0.0
Date: Aug 2018
Status: Confidential





Directory

1.	Introduction	3
	1.1 Overview	
	1.2 Compatibility	
	1.3 Version	
	1.4 Corrections	
2.	Topology	
	Configuration	
	3.1 Server Configuration	
	3.2 Client Configuration	
4		ρ



1. Introduction

1.1 Overview

This document contains information regarding the configuration and use of IPSec_FQDN_Pre shared key and Xauth with CISCO router.

This guide has been written for use by technically competent personnel with a good understanding of the communications technologies used in the product, and of the requirements for their specific application.

1.2 Compatibility

This application note applies to: **Models Shown:** NR500 series.

Firmware Version: V1.0.0(903.0) or newer

Other Compatible Models: None

1.3 Version

Updates between document versions are cumulative. Therefore, the latest document will include all the content of previous versions.


Release Date	Doc. Version	Firmware Version	Change Description
2018/08/03	V1.0.0	V1.0.0(903.0)	First released

1.4 Corrections

Appreciate for corrections or rectifications to this application note, and if any request for new application notes please email to: **support@navigateworx.com**



2. Topology



- 1. NR500 Pro runs as IPSec Client with any kind of IP, which can ping IPSec server IP successfully.
- 2. CISCO router runs as IPSec Server with a static public IP.
- 3. IPSec tunnel is established between NR500 Pro and cisco router.



3. Configuration

3.1 Server Configuration

1. Login to CISCO router and setting like below: cisco2811#show running-config version 12.4 hostname cisco2811 logging message-counter syslog enable secret 5 \$1\$tw/d\$UQQ3Xh06n.2HHFeAVIgXJ.! aga new-model aaa authentication login LOGIN local aga session-id common ip name-server 192.168.111.1 ip address-pool local multilink bundle-name authenticated username cisco password 0 cisco archive log config hidekeys crypto isakmp policy 10 encraes 256 hash md5 authentication pre-share group 5 crypto isakmp key cisco hostname NR500 crypto isakmp identity hostname crypto isakmp peer address 0.0.0.0 set aggressive-mode password ken set aggressive-mode client-endpoint fqdn cisco2811 crypto ipsec transform-set NR500 esp-3des esp-md5-hmac




```
crypto dynamic-map DYN 10
 set transform-set NR500
 set pfs group5
 match address 101
reverse-route
crypto map MAP client authentication list LOGIN
crypto map MAP 10 ipsec-isakmp dynamic DYN
track 1 interface FastEthernet0/0 line-protocol
interface Loopback0
ip address 192.168.50.1 255.255.255.0
interface FastEthernet0/0
 ip address 192.168.111.254 255.255.255.0
 ip nat outside
 ip nat enable
 ip virtual-reassembly
 duplex full
no mop enabled
 crypto map MAP
interface FastEthernet0/1
 ip address 192.168.5.1 255.255.255.0
 ip nat inside
 ip nat enable
 ip virtual-reassembly
 duplex auto
ip forward-protocol nd
ip route 0.0.0.0 0.0.0.0 192.168.111.1
ip nat inside source list 10 interface FastEthernet0/0 overload
ip access-list extended VPN
 permit ip 192.168.50.0 0.0.0.255 192.168.6.0 0.0.0.255
access-list 10 permit 192.168.5.0 0.0.0.255
access-list 101 permit ip 192.168.50.0 0.0.0.255 192.168.6.0 0.0.0.255
line con 0
line vty 5 15
end
```




3.2 Client Configuration

1. Go to **VPN>IPSec>IPSec>General Settings**, click the Edit Button and configure IPSec VPN as below picture. Click Save.



- 2. Click Save>Apply.
- 3.IPSec had been connected successfully. Go to **VPN>IPSec>Status** to check the connection status.






4. Testing

1. Ping from CISCO router to NR500, LAN to LAN communication is working correctly.

2. Ping from NR500 to CISCO router, LAN to LAN communication is working correctly.



3. Test successfully.